

SHOWER NICHE INSTALLATION INSTRUCTIONS

IMPORTANT

- Prior to installation, all parts and components should be thoroughly inspected for defects. This product will not be warranted if it has been installed with pre-existing defects.
- This product should be installed by a licensed tradesperson.
- It is the installer's responsibility to ensure that this product is installed in compliance with relevant local, national and state building codes.

WATERPROOFING

We recommend waterproofing the niche prior to the application of tiles to remain consistent with local building regulation

INSTALLATION

1. Measure the height of the niche and install noggins to suit. The distance between the vertical and horizontal studs must match the dimensions of the niche.
2. Place the niche into position and secure it to the studs with the included screws.
NOTE: Use a screwdriver or a cordless drill on a low speed setting. Do not overtighten. Cracks in the niche due to overtightened screws will not be covered by warranty.
3. Install the wall sheeting, ensuring that it is butted up against the niche.
4. Apply a suitable shower polyurethane sealant to fill the gap between the niche and the sheeting, also filling the void on top of the screw heads.
5. Your niche is structural and waterproof however you will need to ensure the joint from the lip of the niche to your plaster board is totally waterproof in accordance with local building codes. Please follow the recommended waterproofing instructions provided by waterproof manufactures.
6. Apply tile adhesive and tile onto waterproofed membrane surface of the niche.

