

INSTRUCTIONS

1 Identify appropriate pre-drilled holes on the inside of the assembled unit to gain correct shelf height.

2 Insert 2 shelf supports into pre-drilled holes on each side panel of the unit, to ensure an event support for the shelf (4 supports are supplied with this shelf pack).

3 Insert the extra shelf so it rests on shelf supports (white edge strip facing the front).

4 Test shelf strength before loading.
SHELF WEIGHT LIMIT = 30KG

5 To create your own shelf height mark the position for new holes on the inside of the assembled unit and ensure all holes are level. Use a 5mm drill and drill to a depth of 8mm.
Repeat steps 2-4.



www.bedfordfurniture.com.au



Bedford[®]
Changing Lives