

FEAST WATSON TIMBER FLOOR WAX

PREPARATION

Let's get that Matt glow!

Punch exposed nails below the surface. Note that holes and imperfections should be filled with timber putty after the first coat of Timber Floor Wax to match the putty colour with the coated timber colour.

Sand timber to an even, smooth surface. Vacuum and wipe to remove dust.

Previously Coated Surfaces

Previous coatings need to be removed by sanding surface back to bare timber.

Previous coatings of Timber Floor Wax or Floor Seal Oil can be recoated without resanding.

FEAST WATSON TIMBER FLOOR WAX

APPLICATION

Surfaces to be coated must be dry and free from all dirt, dust, grease or polish.

Timber Floor Wax should be stirred thoroughly before and during application with a flat blade stirrer taking care not to introduce bubbles.

Apply a coat of Timber Floor Wax to the timber with a brush, roller or cloth. Ensure the surface is evenly covered.

Once first coat is thoroughly dry, any grain raise can be removed by lightly sanding with 240 grit sandpaper, being careful not to sand through the coating.

When the first coat is thoroughly dry. Apply a second coat of Timber Floor Wax following the application process outlined above.

Do NOT apply in temperatures under 10°C or over 35°C.

FEAST WATSON TIMBER FLOOR WAX

MAINTAINANCE

Allow Timber Floor Wax to cure for a minimum of 4 weeks before cleaning.

Regularly clean floors using Feast Watson Floorclean.

When the surface requires an additional coat, clean with Feast Watson Floorclean and allow surface to dry fully. Apply one coat of Timber Floor Wax as per application directions.