





EZ Glaze™ 50 | Installation Guide



EZ Glaze™ -Product Page



Installations video





PALRAM Webseite





Installation


Safety comes first




Do not step directly on the sheets between the purlins!
When installing EZ Glaze or doing maintenance work, always use stepping ladders or crawling boards, supported by minimum three roof structural elements.




Required Tools




Drill



Electric screwdriver




Ladder




Circular saw

or





Jigsaw




Measuring tape

1 Rafter spacing




Top corrugation (overlapping) is larger than the lower one



Bottom smaller corrugation (overlapped)

- **EZ Glaze 50 is designed for rafters whose width is 50mm or less.**
- Distance between rafters must be 600 mm (center to center).
- Make sure the rafters are perfectly perpendicular to the beams/wall.
- EZ Glaze requires rafters support only, no purlins are required.


2 Minimum Roof Slope



- To ensure proper water runoff, slope should be at least 5% (50mm rise over 1m length).


Installation

* EZ Glaze - Installation direction recommendation




Set the EZ Glaze panels according to the direction recommendation instruction to reduce the cumulative deflection when installing a large number of panels.

3 Foam tape application (optional)




Applying foamed tape on each rafter will reduce friction and noise due to thermal expansion.

4 Setting the first EZ Glaze panel



- Set the first EZ Glaze panel on the rafters, leaving 50-150mm overhang.
- **Drill** 10 mm holes along the outer corrugation, every 500mm.
- First and last drills should be located 30mm-50mm from the rafter's top and bottom edges.

5 Fixing the first EZ Glaze panel




Use Self-Tapping screw
50mmx6.5mm
with 25mm EPDM washer

Fix the first EZ Glaze panel's outer corrugation, using specified screws and washers through the pre-drilled holes. Start at the bottom edge and work your way up.


Installation

6 Setting the second EZ Glaze panel




- Set the second panel, lateral overlapping the first one.
- Drill 10mm holes through **both** panels on the lateral overlap, every 500mm.

7 Fixing the second EZ Glaze panel




Fix both panels together, using specified screws and washers through the pre-drilled holes. Start at the bottom edge and work your way up.

8 Completing the installation




Repeat stage 6 & 7 with the remaining panels.

9 Applying Butyl tape




Installation - Finishing


10 Installing Head Wall Flashing (Purchased Separately)



11 Applying Silicone (purchased separately)





12 Side Wall Flashing (Purchased Separately)





* Side Wall finish when the panel is trimmed (Purchased Separately)







Installation to side wall



Installation to side wall



Installation variation and directions



PALRAM SA/NT
517A Cross keys Road
Cavan SA 5094
Tel: (08) 8262 2288
Fax: (08) 8262 3388
salessa@palram.com

PALRAM NSW/ACT
Unit 2, 26 Redfern St,
Wetherill Park, NSW 2764
Tel: (02) 8788 6100
Fax: (02) 8788 6199
salesnsw@palram.com

PALRAM QLD
Unit 9C / 380 Bilsen Road
Geebung QLD 4034
Tel: (07) 3172 5581
Fax: (07) 3172 5516
salesqld@palram.com

PALRAM VIC/TAS
34 Buys Court
Derrimut VIC 3030
Tel: (03) 9219 4444
Fax: (03) 9219 4455
salesvic@palram.com

PALRAM WA
74 Christable Way
Landsdale WA 6065
Tel: (08) 9302 4173
Fax: (08) 9302 5287
saleswa@palram.com



604344 - 01 2023