



Duratac Installation Instructions

Installation of Duratac Hazard/Directional Tiles

Do not install Tactile tiles directly onto the following surfaces:

- Asphalt
- Exposed aggregate concrete
- Concrete that is less than 14 days old

For these surfaces, use Selleys Kwik Grip Spray Adhesive. Please follow the instructions below for using this adhesive.

Steps for Installation on Stone, Timber or Concrete (that is more than 14 Days old):

1. Ensure the surface is dry and free from dust. Use acetone to clean the surface thoroughly, making sure to remove any excess acetone before proceeding.
2. Peel the backing off the Tactile tile and place it in the desired position.

Installation Using Selleys Kwik Grip Spray Adhesive:

1. Ensure the area is free from dust.
2. Use masking tape to outline the area where the adhesive will be applied.
3. Spray the entire masked-off area with Selleys Kwik Grip Spray Adhesive.
4. Once the adhesive is dry, remove the masking tape. Proceed with installing the Tactile tiles according to the standard installation instructions above.

Tips for a Successful Installation:

To prevent water from pooling behind the Fastiles (which can cause pedestrians to get wet feet and result in the tiles lifting over time), follow these recommendations:

- Leave a gap of approximately 1-2mm between the tiles and any adjacent walls or curbs.
- For areas where the Tactile tiles cover more than 3 meters in length, create a break at a handrail (as tiles only need to cover the width of the travel path). If no handrail is available within 3 meters, leave a 5mm gap between tiles every 3 meters.

By following these guidelines, you'll ensure a more durable and long-lasting installation