flyscreen

MAGNETIC DOOR CURTAIN











INSECT PROTECTION

PROVIDES AIRFLOW

Components List







1 x Hook tape/top strip 1 x Pack of side hook tape tabs

INSTALLATION INSTRUCTIONS



Clean door frame to remove any dirt or grease.



Carefully attach the top strip horizontally.



Align and attach the left side panel of door curtain to top strip.



Align and attach right side panel of door curtain to top strip.



Remove side hook tape backing from tabs and fit to sides of curtain.



Fix sides to frame ensuring the centre strip magnet aligns.

