

ROLLTRAK

DOOR & WINDOW SPECIALISTS

BARN DOOR RECESSED HANDLE

Model Number:	Tools required:
R90130 & R90135	Drill, tape measure, pencil, phillips head screwdriver, hammer, chisel.

