

## **3 PIECE LAMAI WICKER CORNER SOFA ASSEMBLY INSTRUCTIONS**

Please check that all bolts are secure before and after use.

Care Instructions:


- 1. Wipe clean with luke warm water & mild detergent or scrub with soft bristle brush.
- 2. Rinse excess detergent with water and allow to dry naturally.
- 3. It is recommended to store the lounge and cushions out of direct sunlight and rain when not in use.
- 4. To reduce the risk of rust, ensure any scratches/chips to the powder coated steel frame, are coated with a suitable metal coating.

Parts List			
Part No.	Pictures	Description	Quantity
А		Side frame-right	1PC
В		Side frame-left	1PC
С		Back frame-small	1PC
D		Back frame-large	1PC
E		Seat frame	1PC
F		Chaise lounge seat frame	1PC
G		Table frame	4PCS



Part No.	Pictures	Description	Quantity
н		Cover board	1PC
I		Glass	1PC
J		Back cushion	3PCS
к		2-seater lounge seat cushion	1PC
L		Chaise lounge seat cushion	1PC
М	Dimonstanting M6x35mm	Short bolt	4PCS
Ν	(a)))))) M6x45mm	Long bolt	2PCS
0	0	Washer	6PCS
Р	9	Nut	2PCS
Q		Allen key	1PC
R	2	Spanner	1PC









The below instructions show the assembly of the sofa set with chaise lounge on the right. However, you are free to choose which side of the set you would like the chaise lounge to be - left or right.

Note: to assemble the chaise to the left simply swap frame D and C.



## ASSEMBLING YOUR LAMAI CORNER SOFA



## Step 1:

Join the side frame-left (B) with the back frame-large (D) by inserting the hook down into corresponding groove on frame (B). Secure the frames with short bolt (M) and washer (O) into the corresponding threaded hole, loosely tighten.



