27939 - LA-PNCNLAN-2-4 Operating Instructions and Precautions 11162302

Charging: This product is rechargeable. Please charge fully before first use to ensure optimal performance.

Plug the large connector of the included charging cable into any USB power source such as a power cube, computer or car charger. Pull back the charging port cover and insert the USC-C connector. The power switch changes to red while charging and green when fully charged. A full charge takes up to 2 hours.

Operation: The lantern features 4 light modes, all selectable by repeatedly pressing the power switch. Choose warm white (2700K), white (6000K), warm white + white pulse mode, and warm white + white continuous.

You may dim or brighten the light intensity in all modes except pulse by long pressing the power button. Release the button at the desired brightness. If the light blinks, you have reached the highest or lowest brightness for the current mode.

If you press the power button after the light has been on for 10 seconds or more in any mode, the light turns off rather than advancing to the next mode.

The rubber handle may be used for carrying or hanging.

Caution! This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions!