## **G8SAFE GATE HINGES** INSTALLATION GUIDE

### **ADJUSTABLE SELF-CLOSING PAIR** (Suitable for Pool & Garden) **HEAVY DUTY ADJUSTABLE SELF-CLOSING PAIR** (Suitable for Garden)


Before installing a pool hinges, check with your local Council regarding specific pool fence requirements. Note: Images may differ slightly from actual product.

#### Contains:

- » 2 x Hinges
- » 1 x Safety Cap
- » 1 x Allen Key
- » 1 x Finishing Cap
- » Installation guide

### Tools required:


- » Drill
- » Measuring tape
- Phillips head screwdriver





Align gate with post Post Gate

2. Align gate with hinge post and fix off hinges to post.

1. Mark and fix hinges to gate.







**3b.** Once adjusted, fit the supplied caps to the top. To avoid kids climbing, the Safety Cone MUST be fitted to the bottom hinge.

- **3a.** To adjust hinge tension, simply use supplied tool:
  - » ONE tension click per hinge at a time.
  - Check for desired gate tension after each adjustment. Gate must be able to self close from any open position.
  - » Aim for equal amounts of tension clicks on each hinge if possible.
  - » Maximum FOUR tension clicks per hinge.

#### NOTE:

- » Before installing pool hinges, check with your local Council regarding specific pool fence requirements.
- » Must be installed in accordance with the local fence / barrier codes and regulations.
- » Maintain latch and hinges regularly, making sure that latching hook, striker bolt and other moving parts from latch and hinges are free from debris.
- » Please, note that these hinges are designed for non-automated gates. The use for other purposes may affect performance.
- » These latch and hinges will operate correctly only if installed and maintained in accordance with ProtectorAl™ instructions.
- » Images may differ slightly from actual product.







# **G8SAFE GATE HINGES** INSTALLATION GUIDE

**SELF-CLOSING PAIR** (Suitable for Pool & Garden) NON SELF-CLOSING PAIR (Suitable for Garden)

Before installing a pool hinges, check with your local Council regarding specific pool fence requirements. Note: Images may differ slightly from actual product.


Contains:

Comes with:

- » 2 Hinges
- » Screws
- » Installation guide

Tools required:


- » Drill
- » Measuring tape
- Phillips head screwdriver



1. Mark and fix hinges to gate.



3. For hinges with support legs also fix to post.



**2.** Align gate with hinge post and fix off hinges to post.

- » Before installing pool hinges, check with your local Council regarding specific pool fence requirements.
- » Must be installed in accordance with the local fence / barrier codes and regulations.
- » Maintain latch and hinges regularly, making sure that latching hook, striker bolt and other moving parts from latch and hinges are free from debris.
- » Please, note that these hinges are designed for non-automated gates. The use for other purposes may affect performance.
- » These latch and hinges will operate correctly only if installed and maintained in accordance with ProtectorAl<sup>TM</sup> instructions.
- » Images may differ slightly from actual product.





