

INSTALLATION INSTRUCTIONS

Flexible Water Connector

Thank you for purchasing one of our quality Kinetic products.

IMPORTANT!

- Plumbing products must be installed by a licensed plumber in accordance with AS/NZS 3500 and local or state regulations.
- **BEFORE** installing flexible hose, read these instructions carefully to ensure proper assemble, installation and usage.
- **BEFORE** using flexible hose, ensure that all components are installed securely.
- **DO NOT** attempt to use flexible hose if any components are damaged or missing. **DO NOT** use alternative substitute parts. Substitute parts will not be covered by product warranty.

INSTALLATION:

1. Turn off water supply and remove old hose.
2. Clean all connecting threads.
3. Install connector. See notes below.
4. Turn water on and inspect for leaks.

NOTES:

- a. Suitable for hot and cold water
- b. Do not over tighten nuts. Loose end nut should be tightened between 5-8 N.M
- c. 1/2" FL x 1/2" FL BSP Class 2 hose
- d. Hose has a 30mm Minimum bend radius. Do not stretch, twist, kink or expose to naked flames or corrosive agents
- e. Operating specifications:
 - Working temperature: min 2°C - max 50°C
 - Pressure limits: min 150kPa - max 500kPa
- g. Flexible hose must be used in an accessible location and not buried or submerged or not in direct uv/sunlight application. Not suitable for use inside walls, ceiling, underground etc

Australia

Kinetic Sourcing Group Pty Ltd
ABN 76 139 962 075
15/3 Box Road,
Caringbah, NSW 2229, Australia
Ph: (02) 9524 2570
Email: sales@kineticsourcing.com.au
Website: www.kineticsourcing.com.au

New Zealand

ACM (NZ) Pty Limited
NZBN 4474052
47 Stonedon Drive, East Tamaki
Auckland 2013, New Zealand
Ph: +64 9320 4515
Email: info@acmhardware.com
Website: www.acmhardware.com
Aftermarket Sales Ph: 0800 744 794