


Desky Adjustable Microphone Boom Arm





INSTRUCTION MANUAL

DESKY

help@desky.com.au
(07) 3088 9131



DESKY



If mounting through the desk drill a hole into your desktop using a 6-8mm drill bit. Insert part C and B into the base (A) and tighten using part D.

