

QuikDial™ 4× Outlet Digital Tap Timer





User Guide



PRODUCT CODE: CO6004

Contents

Overview	4
Main Components	4
Additional Functions	5
Specifications	5
Precautions and Use	6
Setup	7
Battery Installation	7
Setup Process	8
Set Clock	12
Starts	13
Start Time	16
Run Time	17
Set Day	18
Zone	20
Conflicting Starts	22
Removal of All Zones from a Start	23
Operation	24
Automatic Watering	24
Manual Watering	25
Manual Watering	26
No/Suspended Watering Mode	27
Maintenance	28
Cleaning	28
Cold Weather	29
Batteries	29
Troubleshooting	30

Overview

Main Components

- 1. ZONE 1 outlet
- 2. ZONE 2 outlet
- 3. ZONE 3 outlet
- 4. **ZONE 4** outlet
- Each outlet is 20mm BSP with 12mm snap-on connection included

- 6. Tap connection locking nut
- 7. Display
- 8. **ON/OFF**
- 9. MENU DIAL
- Requires 4× AA alkaline batteries only (not included)



Overview (continued)

Additional Functions

- Inactivity on your QuikDial Tap Timer controls for 25 seconds will return to the default system mode displaying the current time
- A Removing the AA batteries will reset all clock and schedule settings
- To reset your QuikDial Tap Timer, remove the batteries for 2 minutes which will return the timer to factory default
- A For use with cold water only

Specifications

T DAY COUEDIN INC	Maria O a controllar
7 DAY SCHEDULING	Mon–Sun selection
WATERING DURATION	1-99 minutes
WORKING PRESSURE	30-1,200kPa
MAXIMUM FLOW RATE	25 L/min
CONNECTIONS	20/25mm BSP inlet / 20mm BSP outlet
WORKING TEMPERATURE	3°C to 50°C
BATTERIES	4× AA alkaline (not included)

Overview (continued)

Precautions and Use

- A Your QuikDial is designed to hang vertically from a tap
- A Do not use in place of irrigation solenoids
- ▲ Use with caution on short run drip systems, these can keep valves open when they need to close. A pressure reducer is recommended


Setup

Battery Installation

Install 4× 1.5V AA
 alkaline batteries into your
 QuikDial Tap Timer, as
 indicated in the battery
 compartment [a]



- The timer screen will flash through ZONE I, ZONE II, ZONE III, ZONE IV as part of start up
- Once the start-up process is complete, the CLOCK will display as follows, with the time separator flashing [b] and the battery indicated as full [c]



Setup Process

Your QuikDial has a simple and intuitive setup system quickly completed in 5 steps





- Your QuikDial has up to 4 START TIMES available
- **1**—99 min per **ZONE**

- 3 ZONES will water sequentially starting from the set START TIME
- 1 or all **ZONES** can be included in each **START**, for a total of up to 16 waterings (4 **ZONES**, 4 times per day) to be set
- As an example, if you set a START with a RUN TIME of 60 min this will give a total of 4 hours of watering when all four ZONES are included in the start
- For automatic watering, you must ensure that the CLOCK, START TIME, RUN TIME, SET DAY and ZONE have all been set correctly


Setup Process

Here is a quick overview to see how all these settings combine into a automated watering schedule for your garden






Setup Process



Setup Process



In addition to **STARTS 1**, **2** and **3**, **START 4** will activate **ZONES** I and III at 6:00 am for 15 minutes on Saturdays. 4× **STARTS** is the maximum available.

Set Clock

- The current time and day of the week is needed as the reference point for your program to work
- The **CLOCK** is in 24hr time (12:00 is midday and 00:00 is midnight)
- To set the clock, turn your
 MENU DIAL anti-clockwise
 (left) or clockwise (right)
 until the time is flashing [a]



Press the MENU DIAL once and the HOUR will flash [b]



Turn the MENU DIAL to set the HOUR of the current time 4. Press the **MENU DIAL** and the **MINUTES** will flash [c]



- 5. Turn the **MENU DIAL** to select the **MINUTES** of the current time
- 6. Press the **MENU DIAL** and **DAYS** will flash [d]



- 7. Turn the **MENU DIAL** to select the current **DAY** of the week
- 8. Press the **MENU DIAL** to complete this step

Starts

- Your QuikDial has up to 4 START TIMES available, these can be used for 1 or both ZONES as needed
- There is a default time set for each START. To see these, turn the MENU DIAL clockwise (right)
- While START 1 is on, STARTS 2, 3 and 4 are set to OFF
- The **START TIMES** are in 24hr time
- 12:00 is midnight and 12:00 is midday
- Default START TIMES are as follows:
- **⊘ START 1**—07:30
- **⊘ START 2**—09:30
- START 3—15:30 (3.30pm)
- START 4─18:30 (6.30pm)









Turn a Start On/Off

- Begin by turning the MENU DIAL clockwise (right) until you see the START NUMBER (1, 2, 3 or 4) you want to select
- **1** If the **START** is **OFF** and you need to turn it **ON**:
- Select the START NUMBER by turning the MENU DIAL
- 2. Press the **MENU DIAL** and a flashing **ON** will be displayed [a]



3. Press the **MENU DIAL** to confirm the **START** as **ON**

4. The START NUMBER will now flash [b]—
indicating you can now move to the next start

THE THE START NUMBER

WILL DO NO TO WE TH FR SA SU

 Turn the MENU DIAL to the next START and repeat the process to turn ON/ OFF the other STARTS

Turn a Start On/Off

- f the START is ON and you need to turn it OFF:
- 1 Select the **START NUMBER** by turning the MENU DIAL
- 2. Press the **MENU DIAL** once. a flashing menu box will appear around **START TIME** [C]
- 4 Press the MENII DIAL to confirm the start as OFF
- The START NUMBER will now flash [e]-this indicates you can now move to the next START е



Turn the MENU DIAL anti-clockwise (right) and a flashing OFF will be displayed [d]



Turn the **MENU DIAL** to the next START and repeat

OFF

the process to turn ON/ OFF the other STARTS

Start Time

- START TIME is the time of day your watering begins
- Your *QuikDial* waters each **ZONE** sequentially starting from this time. **ZONES** are added at a later step—refer to <u>ZONE</u> setup instructions to learn more
- To set the watering START TIME for your active START/S:
- Select the START NUMBER
 by turning the MENU DIAL
 clockwise (right)
- Active STARTS have the START NUMBER [a] and ON [b] displayed on the screen



3. Press the **MENU DIAL** once, the menu box around **START TIME** will flash [c]



4. Press the **MENU DIAL**again and **HOURS** will
flash [d], indicating **HOURS** can now be set



Turn the MENU DIAL left or right to set to your preferred HOUR for the START TIME

Start Time

6. Press the **MENU DIAL** again and the **MINUTES** will now flash [e]



- Turn the MENU DIAL left or right to set the MINUTES
- Once the MINUTES
 are correct, press the
 MENU DIAL again to
 move on to RUN TIME

Run Time

- RUN TIME is the watering duration for your START
- You can set 1 RUN TIME per START
- Min. RUN TIME is 1 min
- Max. RUN TIME is 99 min
- **1 RUN TIME** applies to each **70NF** in the **START**
- As an example, if you set a **RUN TIME** of 60 min this will give a total of 4 hrs of watering when all **ZONES** are included in the **START**.

- RUN TIME can be accessed two ways—either as a continuation from the START TIME, or using the following steps:
- Turn the MENU DIAL to select the START NUMBER
- Press the MENU DIAL, and the menu box will flash around START TIME [a]



Run Time

3. Turn the **MENU DIAL** clockwise (right), and the menu box will now flash around **RUN TIME** [b]



4. Press the **MENU DIAL** once and the **RUN TIME** will begin flashing [c]



- 5. Turn the **MENU DIAL** to the desired **RUN TIME** (up to 99 min)
- 6. Press the **MENU DIAL** again to move on to **SET DAY**

Set Day

- Your *QuikDial* allows you to select the days of the week to water
- A There is no interval watering option
- The 7 days of the week are represented with their first two letters. M0 for Monday, TU for Tuesday etc.
- SET DAY allows you to select (or change) the day/s you wish to water either as a continuation from the RUN TIME or using the following steps:
- Turn the MENU DIAL to select the START NUMBER
- 2. Press the MENU DIAL
- The menu box will flash around START TIME [a]



Set Day

Turn the **MENU DIAL** clockwise (right), until a box
 is flashing around **SET DAY** and lines are flashing below
 the days of the week [b]



- Press the MENU DIAL once and a solid line will flash below MO only [c]
 - To keep MO selected, turn the MENU DIAL clockwise (right) to move to the next day
 - b. To remove **MO** press the **MENU DIAL**, **MO** will be removed from the screen
- TONE I THE DESI SOME THE FR SA SU

- 6. Turn the **MENU DIAL** clockwise (right) to move to **TU**
- Repeat for each day, pressing the MENU DIAL to remove days as needed
- If a day is removed by accident, turn the MENU DIAL anti-clockwise until the line is flashing under the removed day. Press the MENU DIAL again to reinstate the day
- Only the days which are included in the **START** will be displayed
- 8. Once you have set/removed **SU** all lines will flash[d]



Press the MENU DIAL again to move on to ZONE

Zone

- A START will remain
 OFF if no ZONES are
 selected for the START
- ZONES can be set up either with a separate START (when needed to water on different DAYS or different START TIMES), or set up within the same START
- All STARTS have ZONE I selected by default
- You can change to another ZONE or select all ZONES via the ZONE menu
- When ZONES are set to water within the same START your QuikDial will water each zone sequentially starting from the set START TIME

- 3 ZONE can be accessed two ways—either as a continuation from the SET DAY, or using the following steps:
- 1. Turn the **MENU DIAL** to select the **START NUMBER**
- 2. Press the MENU DIAL
- The menu box will flash around START TIME
- 4. Turn the **MENU DIAL** clockwise (right) until a box is flashing around **ZONE** [a]




Press the MENU DIAL to confirm you'd like to update the ZONE menu

Zone

6. ZONE I will flash [b]

- Pressing the MENU DIAL once when the ZONE is flashing will allow you to select or delete the ZONE from the START
- As ZONE I is already programmed to water during this START, you can:
 - a. Move onto step 7 to keep **ZONE I** selected
 - b. Press the **MENU DIAL** to remove **ZONE I** from the **START**

7. Turn the **MENU DIAL** clockwise (right) and **ZONE II** [c] will flash



- As **ZONE II** is not programmed to water during this **START**, you can:
 - a. Press the MENU DIAL to select ZONE II for the START
 - b. Turn the **MENU DIAL** clockwise (right) and repeat for zones III and IV as needed

Conflicting Starts

- A If more than one START has been set with the same START TIME and SET DAYS, the timer will ignore the duplication. Only the first start will be run in these cases
- Use the 4 available
 STARTS to spread out your
 watering needs—avoiding
 conflicting STARTS

Removal of All Zones from a Start

- A START will not allow you to turn it ON until a ZONE is selected for the START
- If any active (ON) START/S have all ZONES deselected and turned off, you will need to add a ZONE back to restore the START
- To restore the ZONE/S, turn the MENU DIAL to select the START NUMBER

- 2. Press the MENU DIAL
- 3. A box will flash around **START TIME**
- 4. Turn the dial anti-clockwise (left) until you enter

 ZONE selection, a
 box will flash around

 ZONE—refer to step 5 in

 ZONE setup instructions
 to continue to
 restore ZONES

Operation


Automatic Watering

- Ensure CLOCK,
 START TIME, RUN TIME,
 SET DAY and ZONE have
 all been set correctly
- Pressing the **ON/OFF** button during an automatic program stops it from watering
- After 25 seconds of inactivity on your QuikDial controls, the set watering schedule will be active in the background as per your confirmed settings
- In this state, your QuikDial display will cycle between the CLOCK [a] and the START TIME of your next watering session [b]

- When the **CLOCK** [a] and **START TIME** [b] match, the **ZONE/S** will start watering in seguential order
- During watering, the sprinkler animation [c] will be active and the current

 TONE [c] will floob.

 TONE [c] will floob.



- Additional zones scheduled for watering will also show [e]
- Your timer will have a three second period of 00 before ending a watering or moving to the next ZONE

Operation (continued)

Manual Watering

- By default, the pre-set manual **RUN TIME** is 5 min
- For manual (instant) watering, press **ON/OFF**
- 2. **ZONE I** will flash [a], turn the **MENU DIAL** to select a **ZONE**



- 3. Press the **MENU DIAL** to confirm your **ZONE** selection
- To water for the pre-set manual RUN TIME, wait a short period of time for the RUN TIME to stop flashing [b], indicating it has been set



During watering, the sprinkler animation will be active [c] and the selected ZONE [d] will flash



5. To adjust the manual RUN TIME, turn MENU DIAL when the RUN TIME is flashing [b]



- Min. manual

 RUN TIME is 1 min
- Max. manual RUN TIME is 99 min

Operation (continued)

Manual Watering

- 6. Press the MENU DIAL to confirm your selection
- After a short period of time, the RUN TIME will stop flashing to indicate it has been set
- If the RUN TIME stops flashing before you were able to adjust it—press ON/OFF to stop watering and restart the MANUAL WATERING process from step 1
- To stop watering before the remaining time has lapsed, press ON/OFF and your QuikDial will return to the default display

Operation (continued)

No/Suspended Watering Mode

- To stop all automatic
 watering, press the
 MENU DIAL for 3 seconds
- 2. The display will enter **NON WATERING MODE** [a]
- THE THE ST ZONE MO
- To return to scheduled automatic watering, press the MENU DIAL for 3 seconds
- The **NON WATERING ICON** will disappear and your
 automated watering
 will continue



Maintenance

Cleaning

- Check and clean your filter washer at least twice a year
- Debris can be removed with a soft toothbrush and suitable cleaner where needed (white vinegar/CLR)
- 1 Damaged filters/washers should be replaced
- In hard water areas, further cleaning may be required after periods of no use—as minerals will set in the body of the timer
- Remove all tap fittings and the neck assembly from the timer
- Your timer will need to be stable and upright—an egg carton (or similar) may assist with this
- 3. Make a 50/50 white vinegar and water solution—pour this into the top of your timer
- Allow it to sit for 10 min then empty the timer and rinse well

- 5. Turn the timer upside down and repeat this on each outlet (fill outlet with solution, allow to sit, empty and rinse well)
- ▲ Do not immerse your timer in cleaning solution

Maintenance (continued)

Cold Weather

- Your QuikDial should be removed from the tap and stored away during winter
- ▲ Keep your *QuikDial* out of freezing conditions as this can damage internal components

Batteries

- Remove batteries from your QuikDial during periods of non-use—this will erase all settings
- ▲ Battery leakage can cause corrosion and damage to your *QuikDial*
- A Please only use quality alkaline batteries in your tap timer
- ▲ Do not mix old and new batteries
- ▲ Do not use rechargeable batteries

Troubleshooting

Question	Answer
Why won't my timer stop watering?	✓ If your QuikDial Tap Timer is installed on a short run or pressure compensating system, there can be issues with the valve closing
	This is due to more water on offer than can exit the system— creating a pressure differential
	This can be mitigated using a pressure reducer
	✓ Your timer may have a blockage preventing the valve from closing—contact customer service at support@holmanindustries.com.au for assistance
Why is there no water coming into the system?	Check if the filter is clogged, clean if required—refer to Cleaning for more information
	Check for blockages in the sprinkler/ emitter, clean if required
	There may be an airlock—remove your timer from the tap and give it a shake to displace the airlock

Need help? Just ask!

The Holman website has a host of additional information on features. Head to support.holmanindustries.com.au for more tips, tricks and support content.

support.holmanindustries.com.au for more tips, tricks and support content.

If you still need help, feel free to email our friendly Customer Service team at support@holmanindustries.com.au.





We really appreciate having you as a customer, and would like to say thank you for choosing us.

We recommend registering your new product on our website. This will ensure we have a copy of your purchase and activate an extended warranty. Keep up to date to with relevant product information and special offers available through our newsletter.

www.holmanindustries.com.au/product-registration/

