



URBAN

WARNING SERIOUS INJURY OR DEATH CAN BE CAUSED BY TOPPLING FURNITURE

TO HELP PREVENT A TIP-OVER:

- Anchor this product to a wall or other suitable surface with the provided bracket.
- Check anchors regularly.

FOR MORE INFORMATION SEARCH: www.productsafety.gov.au

5 BASKET STORAGE UNIT

HEIGHT | WIDTH | DEPTH
1100mm | **750mm** | **460mm**

MATTE BLACK METAL

Very Important: Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid, level surface. You will need the assistance of a second person during assembly.
Safety tip: For added safety and support we recommend you fix unit to a wall.
You will need the following: Phillips head screwdriver.

SAFETY TIP:
 When assembling or installing this product wear protective gloves and eyewear.

Parts List:

Frame x 2
 Shelf x 1
 Wire Basket x 5
 Screw x 6
 Shelf Support x 4
 Cross Brace x 1
 Drawer Runners x 10

NOT TO SCALE

PLEASE NOTE: Tip-over prevention bracket x2 included (refer to last step for installation).

Step 1

Align the cross-bracing to the 3 holes on the back of the frame and fix with the provided screws.

Please note: Adjustable feet on the frame should be positioned at the bottom.

Step 2

Repeat step 1 for the remaining frame.

Please note: Adjustable feet on the frame should be positioned at the bottom.

Step 3

Attach 4x shelf supports to the top corner slots on each frame and place 1x shelf.

Please note: Ensure shelf sits firmly on the shelf supports

Step 4

Attach the drawer runners at your desired heights by pressing them into the slots on the frame.

Please note: Wheels on the runners should be facing the front of the unit.

Step 5

Please note: For stability and safety, fix the unit to a wall with the provided brackets. Place the brackets over the rear frame legs and attach to your wall. Necessary fixings for these brackets can be found at your local hardware store.

WARRANTY CONDITIONS: Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under this warranty, take the product (with proof of purchase) to any Bunnings store (for AUS customers see www.bunnings.com.au and for NZ customers see www.bunnings.co.nz for store locations). Pinnacle Hardware bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof of purchase to our support centre for consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law. Our goods come with guarantees that cannot be excluded under the Australian consumer law or Consumer Guarantees Act 1993 (NZ). You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty excludes damage resulting from product misuse or product neglect, any modifications, additions or alterations to the product including the addition of extra shelves. Additions or modifications can compromise the structure and safety of the product. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Pinnacle Hardware, ABN 87 614 496 196, 28 Hudson Court, Keysborough Vic 3173, 1800 349 776, Email: support@pinnacle.net.au. Products sold in New Zealand are imported by Bunnings New Zealand. 'Pinnacle' is a trademark. © Pinnacle Hardware. Suitable for model number W0S00B.