Carbon Monoxide Alarm

The alarm sounds a short beep The battery is low. The alarm will need to be replaced. and the Red LED flashes Model simultaneously every minute. NV968 The alarm beeps 3 times and the The alarm has reached The alarm will need to be replaced. Yellow LED flashes **Battery Type** the end of its life. simultaneously every 48 seconds. Sealed 3V lithium, non replaceable The alarm beeps twice and the The alarm will need to be replaced. The alarm is defective. Yellow LED flashes **Temperature Range** simultaneously every minute. -10° C to $+40^{\circ}$ C Depress the Test/Silence button to silence the **Humidity Range** The alarm beeps 4 times quickly The alarm has had a false and the Red I ED flashes activation. alarm and as a precaution ventilate the area. 30%RH to 90%RH simultaneously every 5 seconds but you can find nothing which The alarm can be activated by things such as could be emitting carbon methane, propane, alcohol-based-products, paints, thinners, solvents, adhesives, monoxide. hairsprays, after shaves, perfumes and cleaning supplies.

CAUSE

CO Alarm Troubleshooting Guide

SOLUTION

Armo

PROBLEM

Click here for User Guide

or browse to https://newfield.help/nv968

© NEWFIELD GROUP Feb 2023