



MIMOSA®


# Installation Guide

BENTOTA  
DINING TABLE  
200X96CM

**ALUMINIUM**



WoodHeat Transfer Finish





# Assembly Instructions



**Please carefully read the below warnings and instructions. Save the instructions for future reference.**


- 1. Please carefully read all instructions before assembly and use**
- 2. Please separate and identify all parts, ensuring that you have all parts listed**
- 3. To avoid damaging your umbrella, it is recommended that you assemble it on a clean, protected surface**
- 4. Washers must be used when indicated during the assembly process**
- 5. Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.**

PARTS LIST		
CODE	PARTS	QTY.
<b>1</b>	 Table top	1PC
<b>2</b>	 Leg tube	2PC


HARDWARE LIST		
CODE	PARTS	QTY.
<b>A</b>	 Big Washer	6PC
<b>B</b>	 M8x30mm	12PC
<b>C</b>	 Allen Key	1PC
<b>D</b>	 Cap	12PC

# Assembly Instructions

- 1 Secure two legs to table top(1), using bolt(B) and big washer(A). Tighten securely with Allen key (C) and cover with cap (D).



- 2 If the surface is uneven, you can level the table with the adjustable feet. Your coffee table is now ready for use.



## CARE AND CLEANING:

1. TO CLEAN, WIPE WITH DAMP CLOTH. DO NOT USE BLEACH, ACID SOLVENTS OR ABRASIVE CLEANERS ON FRAME PARTS.
2. DURING VARYING WEATHER CONDITIONS AND WINTER PERIOD, WE STRONGLY RECOMMEND THAT IT CAN BE STORED IN A DRY AREA WITH A SUITABLE COVER BEFORE STORAGE, PLEASE ENSURE IT IS CLEAN AND DRY BEFORE STORAGE.
3. IN THE EVENT OF BARE METAL SHOWING DUE TO SCRATCH, IT IS PREFERRED TO TREAT WITH A RUST REPELLING VARNISH OR SIMILAR.
4. PERIODICALLY CHECK AND ENSURE THAT ALL THE SCREWS ARE COMPLETELY TIGHTENED.
5. A PROTECTIVE WEATHER COVER IS ENCOURAGED TO PROLONG THE LIFESPAN OF YOUR LOUNGE.

