

# Low Pressure Tap Timer

**HOLMAN**



PRODUCT CODE  
**CO1603**

## User Guide


www.holmanindustries.com.au

## GLOSSARY

- A. UNIVERSAL TAP ADAPTOR
- B. TAP CONNECTION
- C. UNION NUT
- D. CONTROL DIALS
- E. BATTERY COMPARTMENT
- F. SNAP-ON HOSE CONNECTION

## INSTALLATION

Make sure the filter (washer) is in place, then screw the **Low Pressure Tap Timer** to the tap with the **UNIVERSAL TAP ADAPTOR** end, turn it clockwise (hand tighten only). Connect the **SNAP-ON HOSE CONNECTION** end to your garden hose or system.




## BATTERY INSTALLATION

Hold the **Tap Timer** with the **BATTERY COMPARTMENT** facing you

Remove the **BATTERY COMPARTMENT** cover and the battery tray

1. Insert 2 x AAA alkaline batteries
2. Insert the battery tray and replace the **BATTERY COMPARTMENT** cover. Ensure the battery compartment stays dry



## PROGRAMMING CONTROLS

The **Low Pressure Tap Timer** is programmed using three individual controls. The **LEFT** dial can be turned to select the **INTERVAL** of watering. This is how frequently you want to water. The **RIGHT** dial can be turned to select the **RUN TIME**, this is how long you want the **Tap Timer** to run for.

The **ENTER** button performs two tasks:

1. Press the **ENTER** button to confirm your selections, activating the watering operation. You must hold the **ENTER** button for 3 seconds and the LED will flash
2. **ENTER** can be pressed again after confirming **INTERVAL** and **RUN TIME** and to move the watering **START TIME** forwards by 1 hour to delay it

Every press adds 1 extra hour to your start time (optional). The LED will flash every time you press the **ENTER** button to confirm

**B** The **Tap Timer** will not run immediately after the program is set. Program will commence after the chosen interval duration has lapsed once.




## SET AUTOMATIC WATERING

1. SET THE WATERING INTERVAL

You can adjust the frequency of watering (**INTERVAL**) from 1 hour to 7 days.

To select the frequency, turn the **INTERVAL** dial and select the desired time.




## SET AUTOMATIC WATERING CONT.

2. SET THE WATERING RUN TIME

You can adjust the duration of watering (**RUN TIME**) from 1 to 120 minutes.

To select the duration of watering, turn the **RUN TIME** dial from **OFF** to the desired minutes.



3. CONFIRM THE WATERING OPERATION

Once you have made your selections, press and hold the **ENTER** button for 3 seconds until you see the LED light appear solid. This will now have confirmed the watering operation.



## AUTOMATIC WATERING DELAY

To set a delay in the **START TIME** for watering, immediately after confirming your watering operation, you can press the **ENTER** button again to delay the watering by 1 hour.

## AUTOMATIC WATERING DELAY CONT.


Each press equals 1 extra hours delay. This can be added from 0 - 23 hours depending on your requirements. Each press will be followed by the LED flashing once for confirmation.

1X = +1HR  
2X = +2HR ...and so on.

**WATERING EXAMPLE:** It's 12:00 presently and you want to water at 14:00 for 60 minutes and every two days.

1. Set the watering **INTERVAL** to 48 Hours
2. Set the watering **RUN TIME** to 60 minutes
3. Press and hold **ENTER** to confirm watering operation


4. Press and hold **ENTER** twice to add 2 extra hours delay. Each press will be followed by the LED flashing once for confirmation



## MANUAL WATERING


OPTION 1: Manual Watering

To start Manual Watering, turn the **INTERVAL** dial to **RESET**. Turn the **RUN TIME** dial to **ON**. Turn on your tap and water as needed. To stop watering, turn your tap off. Turn the **RUN TIME** dial to **OFF**, or re-enter the watering operation.



OPTION 2: Manual Watering (Auto-Stop)

To start Manual Watering with an auto-stop, turn the **INTERVAL** dial to **RESET**. Turn the **RUN TIME** dial to the desired time you wish to water for. Turn on your tap, watering will stop once **RUN TIME** minutes have lapsed.



## TECHNICAL DATA

PRODUCT: Low Pressure Tap Timer

PRODUCT CODE: CO1603

MAXIMUM WATER PRESSURE: 600 kPa

BATTERY: Use 2 x AAA ALKALINE batteries

FLUID: Only use cold water with NO added chemicals

FREQUENCY OPTIONS: Every 1 hrs, 2 hrs, 3 hrs, 4 hrs, 6 hrs, 8 hrs, 12 hrs, 24 hrs, 48 hrs, 72 hrs, Week, Reset

RUN TIME OPTIONS: 1, 3, 5, 10, 15, 20, 30, 60, 90, 120, ON, OFF

WARNINGS: Do not use this device without the appropriate filter

Every 4 seconds the LED will flash to confirm the battery is working. If the LED flashes any quicker, please replace the batteries

We really appreciate having you as a customer, and would like to say thank you for choosing us. Should you have any questions about this product or its operation please call customer service on 1300 716 188

**HOLMAN**

For the #SMARTGARDENER

Head Office/Service

11 Walters Drive, Osborne Park WA 6017  
Tel: +61 8 9416 9999 Fax: +61 8 9416 9920  
support@holmanindustries.com.au  
www.holmanindustries.com.au

Copyright © 2020 Holman Industries