

281C

Black









Marquee®
create your own space

3 PCE RATTAN WICKER BISTRO SETTING



3 PCE RATTAN WICKER BISTRO SETTING


Part List

 M6 x 20	
1. 24pcs	2. 24pcs
	
3. 1pc	A. 2pcs
	
B. 4pcs	C. 4pcs
	
D. 2pcs	E. 2pcs
 M6 x 15	
1. 8pcs	2. 8pcs
	
3. 1pc	A. 1pc
	
B. 4pcs	C. 1pc


3 PCE RATTAN WICKER BISTRO SETTING

Assembly Instructions


Step 1




Step 2



Step 3




Step 4



3 PCE RATTAN WICKER BISTRO SETTING

Assembly Instructions

Step 1



Step 2

