

Cashmere 2.1m(7ft) Christmas tree

Classic full shape

Hinged branches with 830 tips

Metal stand included

Tree width 115cm



Contents


A. Tree Top

B. Upper Body

C. Lower Body

D. Metal Stand

Assembly Instructions (**keep for reference**) :



BEFORE YOU START

- The key to beautiful tree is SHAPE. Read instruction carefully before assembling and shaping the tree.
- Carton contains: top section, pole sections with brackets, tree stand.

GETTING STARTED

1. Place the base on a flat surface and turn the branches at 90° (Fig. 1).
2. Fix the bottom part of the tree into the base and tighten the bolts in order to stabilize the tree. Screw the upper part of the tree on the bottom part (Fig. 2).
3. Starting by the bottom of the tree, expand the branches and bringing them towards the lower part (Fig.3).
4. Fix the upper part of the tree. (Fig. 4).
5. Each branch has several sets of three twigs. For each set, you should direct a twig towards the center, the other to the left and the last one to the right (Fig. 4).
6. The tree is now ready to be decorated. (Fig. 5).

STORAGE TIPS

- Remove all lights and ornaments.
- Work bottom to top. Remove each panel, pressing branches against stem.
- Place branches into carton with the longest branches at the bottom.
- Store carton away from heat, and keep in a cool and dry place.

CAUTION:

1. To be assembled by or under supervision of an adult.
2. Do not store tree in damp area or in an area where the temperature exceeds 100°F.
3. Do not light a candle on or near the tree.
4. This product is for indoor use only.
5. Retain the instruction manual for future use.