


## Outdoor Party Pavilion 3mx6m



| No. | tube              | qty |
|-----|-------------------|-----|
| 1   | Roof Canopy pole  | 8   |
| 2   | Roof Canopy pole  | 8   |
| 3   | Frame Canopy pole | 14  |
| 4   | Frame Canopy pole | 7   |
| 5   | Vertical pole     | 6   |
| 6   | Vertical pole     | 6   |

| description         | accessories | qty |
|---------------------|-------------|-----|
| vertex<br>connector | 93          | 2   |
| base                |             | 6   |
| stake               |             | 12  |
| corner              | 4           | 4   |
| rope                | ~           | 6   |
| side<br>connector   | 23          | 2   |

## **Assembly Instructions**

Parts List

Step 1: Assemble the canopy frame using tube No.3 & 4 and corner connectors and side connectors. Lay the parts on the ground and slide them together until the click into position.

Step 2: Assemble the canopy frame using tube No.1,2,3 & 4 and connect to vertex connector

Step 3:Assemble the bottom vertical frame (tubes 5 & 6). Place the bases into the end of tube No.6 and then slide tube No.6 & 5 together. Then slide the other end of tube No.5 into corner/side connectors.

Step 4: After the frame is set up, pull the Party Pavillion cover tightly over the whole frame and place the metal hooks into the first hole on tube No.6. If the cover becomes loose during use, reposition the metal hook into the next hole down until proper tension has been acheived. Secure the Party Pavillion to the ground using the stakes and rope provided. Drive the stakes into the ground at an angle so that the maximum tension can be acheived.

## WARNING:

Your Gazebo is designed mainly for sunshade purposes and is not waterproof. Your Gazebo is a non-permanent structure and do not use in extreme weather conditions including heavy rain or high winds.