




EASYDECK™ Maintenance System

Instruction Manual

EASYDECK™ Maintenance System



1. Fit the Applicator Pad




Open the Latch on the Applicator Body and slide a clean EasyDeck Applicator Pad onto the Applicator Base.




Close the Latch firmly ensuring the Applicator Base is clipped in.

2. Attach the Pole




Position the Pole so that the word "FRONT" is facing forward.




Insert the Pole into the Applicator Body and twist the Collar clockwise until the Pole is securely attached.

3. Insert EasyDeck™ Bottle




TIP: Shake only with the Bottle Cap on, and keep this handy for later use.

Shake the EasyDeck bottle for at least 1 minute to ensure a consistent and premium finish.




Replace Bottle Cap with Dispensing Nozzle and ensure this is firmly screwed on.



TIP: When the Dispensing Nozzle is attached, you can turn the Bottle upside down without it leaking.


Place the EasyDeck Bottle into the Applicator Body and press down firmly.

4. Prime the Pump



TIP: Do this step on your deck. Avoid over pumping.


Unhook the Trigger and squeeze the handle 6-10 times to begin product flow.



TIP: Be patient, liquid can take a couple of moments to work through the EasyDeck™ Applicator Pad.

Ensure the EasyDeck Applicator Pad is saturated enough by moving the **Cabot's** EasyDeck over a small area of decking. Stop squeezing once it leaves a light even coating. If the area is over saturated, refrain from further pumps and begin coating.

5. Get Coating!




Wait 40 minutes for the coating to dry and it's ready to walk on!


TIP: The frequency of Trigger squeezes will depend on the condition of your deck. Avoid excessive coating - a thin even coat gives the best results. You may notice some foaming of the Maintenance Coat during application. Don't worry, this is normal and will not impact the final finish.

For best results, use long, smooth strokes along the direction of the boards. Squeeze the Trigger as needed to achieve a consistent and light coating.

6. Clean up & Storage




Twist and remove the EasyDeck Bottle from the Applicator Body vertically without tilting to avoid ejection of the silicon seal from the Dispensing Nozzle and prevent spillage. Replace the Dispensing Nozzle with the Bottle Cap. Unused EasyDeck coating can be stored upright in a cool, dry area for up to a year.




TIP: It's normal for the coating to leave some staining.

Rinse the Dispensing Nozzle until the valve is clean and the water runs completely clear.




Then, while still under running water, pump the yellow Cleaning Levers to flush water through the mechanism. Continue until the rinsed water is completely clear.




Don't misplace the Dispensing Nozzle. You will need it next time.

TIP: Storing the Dispensing Nozzle within the Applicator Body will help keep this handy for next time.

Let components dry thoroughly before storing in a cool, covered area. Store with or without the Pole attached.



Remove the EasyDeck Applicator Pad and leave to soak, then rinse under running water until the water runs clear and the pad returns to its original colour.



TIP: Detach the Pole for easier cleaning, especially if using a laundry trough.

Rinse the Applicator Body and pad area under running water.

Repeat Use and Important Information

- It is recommended to wait a least 40 days after coating your deck with **Cabot's** EasyDeck Maintenance Coat before reapplying this product.
- The **Cabot's** EasyDeck Maintenance System is recommended for use between normal recoat cycles of **Cabot's** Aquadeck® (or other water based decking oils). Allow at least 30 days after reapplying **Cabot's** Aquadeck (or other water based decking oils) to use **Cabot's** EasyDeck Maintenance System.
- Not compatible with solvent based coatings.
- Not suitable for vertical timber surfaces.
- Conditions of 25°C and 50% relative humidity. More humid or cooler conditions will need longer drying times.

If your deck is showing signs of damage a recoat with Aquadeck is recommended, and then waiting 30 days before using EasyDeck.

The EasyDeck Applicator is designed to be used exclusively with the EasyDeck Maintenance Coat. Regularly replace consumables, such as the **Cabot's** EasyDeck Maintenance Coat and **Cabot's** EasyDeck Applicator Pad when required.

Disposal

The EasyDeck Bottle and Bottle Cap are recyclable when empty and rinsed. However, we encourage you to reuse the EasyDeck Bottle by purchasing the 3L EasyDeck Maintenance Coat refill bottle.

*Subject to local recycling arrangements.

For further information or a copy of the Product Safety Data Sheet telephone Cabot's Help and Advice team on **AUST 1800 011 006** **NZ 0800 222 687**

©Cabot's, Aquadeck and The Squares Device are registered trade marks. EasyDeck is a trade mark.



Scan me for different languages!

Warranty

We are proud to offer a three year warranty on your purchase of the **Cabot's** EasyDeck Applicator. If you experience any issues with your applicator, please fill out a Warranty Claim Form through cabots.com.au/warranty, or contact our friendly Help & Advice Team.

Australian Consumer Law

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You may have a replacement or refund for a major failure, and compensation for any other reasonably foreseeable loss or damage. You may have the goods repaired or replaced if the goods fail to be of acceptable quality, and the failure does not amount to a major failure. The benefits to You under Our warranty are in addition to (and don't exclude, restrict or modify) any other rights and remedies You may have under the Australian Consumer Law.

Cabot's Australia,
1956 Dandenong Road,
Clayton,
Victoria, 3168.
www.cabots.com.au

Cabot's New Zealand
150 Hutt Park Road,
Gracefield,
Lower Hutt, 5010.
www.cabots.co.nz

