



# Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp

## VARIANTS

### Size:

*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 40mm x 4mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 60mm x 6mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 80mm x 8mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 100mm x 10mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 120mm x 12mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 150mm x 16mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 150mm x 20mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 150mm x 24mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 200mm x 28mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 200mm x 32mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 200mm x 36mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 250mm x 40mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 250mm x 44mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 250mm x 48mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 300mm x 52mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 300mm x 56mm*  
*Heeve 900mm Indoor Self-Adhesive Flexible Coloured Threshold Ramp - 300mm x 60mm*

**MAXIMUM WEIGHT CAPACITY: 1000kg**

## INSTALLATION INFORMATION:

- 1. Prepare the Surface:** Ensure the threshold surface is clean, dry, and free of dust, dirt, and debris. Use a damp cloth to clean the area and let it fully dry before proceeding.
- 2. Measure the Area:** Measure the length and width of the threshold to confirm the ramp fits correctly.

If needed, trim the ramp to size using scissors or a cutter for a custom fit.

**3. Peel the Adhesive Backing:** Carefully peel off the protective layer from the adhesive backing on the ramp.

**4. Position the Ramp:** Align the ramp with the threshold, ensuring it fits properly and covers the entire surface.

**5. Apply Pressure:** Firmly press the ramp onto the threshold, starting from the center and moving outward to eliminate air bubbles.

**6. Check for Secure Adhesion:** Press along the edges to ensure the adhesive is securely attached to the floor.

**7. Allow Time to Settle:** Let the ramp sit undisturbed for at least 30 minutes to ensure a strong bond before use.

**8. Test the Ramp:** Walk or roll a light object over the ramp to confirm it is securely installed and level.

#### **SAFETY INFORMATION:**

1. Ensure the surface is clean and dry before applying the self-adhesive ramp.
2. Avoid installing on uneven or rough surfaces to maintain stability.
3. Regularly check the ramp for wear and tear to ensure long-term safety.
4. Do not exceed the maximum weight capacity of 1000kg.
5. Keep the ramp free of debris or liquids to prevent slips or trips.
6. Ensure proper adhesion by pressing firmly after installation.
7. Avoid placing near high heat or open flames, as it is made of rubber.
8. For best results, use indoors as the ramp is designed for indoor environments.

#### **MAINTENANCE:**

1. Made from 100% natural, recycled rubber, promoting eco-friendliness.
2. Designed for long-term durability, reducing the need for frequent replacements.
3. Fully recyclable at the end of its lifecycle, supporting sustainability.
4. Low maintenance design minimises environmental impact over time.
5. Packaging is kept minimal to reduce waste during shipping and storage.

#### **WARRANTY INFORMATION:**

Heeve products come with a one-year warranty covering manufacturer defects, excluding damage from improper use, assembly, storage, or normal wear and tear.