

# Remsafe Lylock

## Sliding aluminium window restrictor



- ✓ Suitable for sliding aluminium windows
- ✓ Complies with safety requirements under the *Strata Schemes Management Act 2015* (NSW)
- ✓ Child resistant release mechanism allows the window to be opened to its full extent if required

### The Remsafe Lylock is supplied with:

1 x Drilling Jig	1 x 1 mm Packing Plate
1 x Key	1 x 2 mm Packing Plate
2 x Screws	

### Installation:

1. With the window in the closed position, place the drilling jig on the vertical frame of the moving window with the cut-out edge resting on the window sill.
2. Mark the two screw fixing holes and the locking pin hole.
3. Use a 2 mm drill piece to drill the screw fixing holes, being careful to avoid the glass under the frame.
4. Use a 6.5 mm drill piece to drill the locking pin hole on the window sill, being careful to avoid drilling too far into the window roller or track.
5. Using the screws provided, screw the lock to the window.  
1 mm or 2 mm packing plates may be required if the window sill is too thick.
6. Check the function of the lock by pushing the lock barrel through the locking pin hole to engage.
7. A second locking pin hole must be made at the restricted opening position. Measure an opening distance of 10 cm (4 inches) and repeat Steps 4 to 6.

### Maintenance:

The manufacturer recommends maintenance is carried out on Remsafe products by a licensed tradesman every twelve (12) months. In addition, it is recommended that regular checks (every three to six months) are carried out by the user of each window safety device at the time of operation. Repeated force on a Remsafe Window Locks safety device may lead to general wear and tear and cause screws to become loose.

Consideration must be given to the local environment and maintenance carried out accordingly.

1. All screws must be checked to ensure they have not loosened. Loose screws must be tightened.
2. All lock components must be checked for any signs of corrosion, cracking, or loss of function. Any locks showing signs of corrosion, cracking, or loss of function must be replaced immediately.
3. All components must be checked to ensure against excessive movement. Any lock showing excessive movement must be replaced immediately.
4. If a window is able to be opened greater than 100 mm at any point a licensed tradesperson should be consulted for advice on the most appropriate window restrictor device for each window.

Warning: Window falls may result in injury or death. Falls from heights may still occur through windows with safety devices installed. To prevent falls from heights, climbable elements should be removed from below windows and children should be supervised around open windows.

**NEVER LEAVE THE KEY UNATTENDED IN ANY REMSAFE WINDOW LOCKS PRODUCT.**

**Remsafe Window Locks offer safety solutions for all window types.**

**Contact us for orders and enquiries on +61 2 9453 5625, email [info@remsafewindowlocks.com.au](mailto:info@remsafewindowlocks.com.au)  
or visit [www.remsafewindowlocks.com.au](http://www.remsafewindowlocks.com.au)**