




SWING
SLIDE
CLIMB

BACKYARD BISTRO MUD KITCHEN ASSEMBLY INSTRUCTIONS



- 1. Stove top
- 2. Counter top

- 3. Blackboard
- 4. Sink

- 5. Cupboard (with door)
- 6. Hooks

BACKYARD BISTRO MUD KITCHEN - SAFETY & WARNINGS

Ensure to read all warnings and instructions in this user guide prior to first use. Failure to assemble and maintain this item as per instruction may cause injury to the user. Please keep the instructions in a safe place for future reference.



WARNING! Not suitable for children under 2 years. Contains small parts.

- This Backyard Bistro Mud Kitchen is suitable for children aged 2-7years.
- This Backyard Bistro Mud Kitchen is only suitable for domestic use and not designed for commercial use.
- The Backyard Bistro Mud Kitchen should only be assembled by adults.
- Adult supervision is always required when children are playing with the Backyard Bistro Mud Kitchen.
- Ensure all screws are fully tightened and secure. Failure to do so may result in injuries.
- Check all coverings for exposed screws and sharp edges.
- If the Backyard Bistro Mud Kitchen is faulty, stop use immediately.
- Ensure regular inspections and maintenance on the Backyard Bistro Mud Kitchen's components are performed.
- Do not fully tighten the screws until assembly is complete.
- Do not modify the Backyard Bistro Mud Kitchen yourself.

The Backyard Bistro Mud Kitchen satisfies all the requirements of the Australian Standard AS/NZ ISO 8124 and has been certified by an independent laboratory.

TIMBER CARE

As timber is a natural product, it will deteriorate in the weather over time. For maximum longevity, it is highly recommended to apply an initial 3 coats of a timber protectant such as paint, lacquer or an exterior grade oil before first use of the play set.

Minor twisting, warping, cracking and any other natural occurring property of wood will occur.

PLEASE NOTE these occurrences are cosmetic and will not affect the strength or integrity of the product. If you have any concerns or queries please contact the after sales service for further assistance.

All outdoor wooden products require routine inspection and regular maintenance. After installation, a follow-up inspection should take place after one week and twice a month thereafter for the remaining life of your play products. Maintenance should be performed at any time it is deemed necessary. As a general rule, major maintenance (wood refinishing) should be performed at 6 month intervals from the date of installation. Inspect the performance base on the following checklist:

- Major wooden parts: Inspect for splintering and structure defects at regular intervals.
- For minor splinters or chipping: lightly sand and refinish with an exterior water repellent stain can assist.
- If the timber has cracked or split significantly, replacement parts may be required. Please contact our After Sales Service for any replacement requirements.
- It is preferable to pre-drill timber before fixing screws to avoid cracks in the timber.
- The dimensions given in the instructions are indicative only, they may vary according to the assembly method.


CAUTION! This product includes timber.
PLEASE KEEP AWAY FROM FIRE.

IMPORTANT: If living in area prone to termites, please ensure any timber is treated with termite protection. Ensure the product does not contain hazardous chemicals once dry that can pose a potential health risk to children.


After Sales Service: 1300 457 272

BACKYARD BISTRO MUD KITCHEN - HARDWARE


















TOOLS REQUIRED




PHILLIPS
SCREWDRIVER




CORDLESS DRILL &
PHILLIPS HEAD DRILL BIT


<div>1</div>  <div>2 PC</div>	<div>2</div>  <div>2 PC</div>	<div>3</div>  <div>2 PC</div>	<div>4</div>  <div>2 PC</div>
<div>5</div>  <div>1 PC</div>	<div>6</div>  <div>1 PC</div>	<div>7</div>  <div>3 PC</div>	<div>8</div>  <div>2 PC</div>
<div>9</div>  <div>4 PC</div>	<div>10</div>  <div>2 PC</div>	<div>11</div>  <div>2 PC</div>	<div>12</div>  <div>1 PC</div>
<div>13</div>  <div>1 PC</div>	<div>14</div>  <div>2 PC</div>	<div>15</div>  <div>1 PC</div>	<div>16</div>  <div>1 PC</div>
<div>17</div>  <div>1 PC</div>			




4x50
26 PC




4x30
8 PC




3x25
54 PC




4 PC




1 PC




1 PC




1 PC




1 PC




4 PC




1 PC




4 PC




4 PC




4 PC




4x15
4 PC



4 PC




1 PC




1 PC

BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

1 4x50 = 16 PIECES




2 4x50 = 4 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

3 4x50 = 4 PIECES




4 3x25 = 12 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

5 4x30 = 2 PIECES




6 3x25 = 10 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

7 3x25 = 24 PIECES




8 3x25 = 4 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

9 4x30 = 4 PIECES




10 4x50 = 2 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

11 4x30 = 2 PIECES




12 4x25 = 4 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

13 4x15 = 4 PIECES




14 4x50 = 4 PIECES




BACKYARD BISTRO MUD KITCHEN - ASSEMBLY INSTRUCTIONS

15



16





swingslideclimb.com.au