

User Manual


Wireless Headphones

HP-KBT25




WHAT'S IN THE BOX

- » Bluetooth headphones
- » USB-A to USB-C charging cable
- » User manual

OVERVIEW



FUNCTION	OPERATION
Charging	Connect USB-C cable to a 5V USB-A power source (wall charger, car charger, laptop/PC, powerbank, etc.). Red light: Charging. Light off: Fully charged. Note: Fully charge before first use.
Power on/off	Press and hold (approx. 5 sec.) ⏻ Power button. Power On: Light blinks red and blue alternately (pairing mode). Power Off: Indicator light turns off.
Turn RGB lights on/off	Press ⏻ Power button 3 times.
Bluetooth pairing	1. Power on headphones. 2. Select HP-KBT25 in your device's (smartphone, tablet, laptop, etc.) Bluetooth settings.
Play/pause	Press ⏻ Power button.
Volume up	Press + button.
Volume down	Press – button.

FUNCTION	OPERATION
Play next track	Press and hold + button.
Play previous track	Press and hold – button.
Answer/end call	Press  Power button.
Reject call	Press and hold  Power button.
Redial	Press  Power button twice.
Activate Voice Assistants (Siri, Google Assistant)	Press and hold (approx. 3 sec.) M button.
Wired connection	Connect AUX cable (not included) to headphones and your device (laptop/PC, MP3 player, radio, etc.). Headphones switch to AUX mode automatically. Start playing audio on your device.
SD card mode	Turn off headphones. Insert Micro SD card (not included) with metal contacts facing RGB light side. Turn headphones back on. Supports MP3, WMA and WAV files.

SAFETY PRECAUTIONS

- » Always supervise children while using the headphones.
- » Keep out of reach of toddlers and infants to avoid choking hazards.
- » Ensure the headband and cables do not wrap around a child's neck.
- » Ensure a snug, comfortable fit for proper audio quality and safety.
- » Limit listening time and encourage regular breaks to prevent ear fatigue.
- » If the headphones become hot during use or charging, unplug and stop using them immediately.
- » An adult should assist with Bluetooth pairing to avoid unknown connections.
- » An adult should handle the charging process. Do not let children charge the headphones.
- » Charge on a flat, dry surface, away from flammable materials.
- » Unplug the headphones once fully charged to prevent overheating.
- » Keep away from moisture, dust and extreme heat.
- » Clean with a soft, dry cloth. Avoid harsh chemicals.
- » Check for damage regularly. Stop using if parts are cracked, frayed or broken.
- » Do not disassemble.
- » Follow local laws for proper disposal and battery recycling; avoid putting it in kerbside bins.

TROUBLESHOOTING

Headphones will not turn on:

- » Charge the battery.

No sound:

- » Check volume level on headphones and connected device.
- » Check Bluetooth connection.

Cannot pair Bluetooth device with headphones:


- » Keep headphones next to your device during pairing.
- » Ensure AUX cable is disconnected.
- » Ensure headphones are in pairing mode. Turn off and on again to switch to pairing mode.
- » If headphones are paired to another device, disconnect before connecting to your device.
- » If headphone's Bluetooth name is not found, refresh or search again. Wait up to 1 minute for device to appear.

SPECIFICATIONS

- » Model: HP-KBT25AQ-140, HP-KBT25BK-133, HP-KBT25PP-294
- » Audio inputs: Bluetooth, 3.5mm AUX, Micro SD
- » Bluetooth pairing name: HP-KBT25
- » Bluetooth version: 5.4
- » Bluetooth range: 10m (unobstructed)
- » Micro SD card: up to 32GB in FAT32 file format
- » Battery capacity: 200mAh
- » Charging time: Approx. 1.5 hours
- » Charging power input: 5V, 1A

HELP

Scan the QR code or go to: <https://help.laserco.com.au/support/home>. Enter your model number to find troubleshooting steps, FAQs and other helpful information.



Product design, actual colour, features and specifications are subject to change without prior notice.

LASER

Product Support:

P: (02) 9870 3388

E: support@laserco.com.au

W: www.laserco.com.au/warranty