

jumbuck®



WARNING

Curing your chimenea accustoms it to the heat ensuring that it is much less likely to crack when being exposed to high temperatures. Follow the below steps prior to any use.

Full product instructions are contained in the user manual.

Step 1 – Place your chimenea in a safe place

Make sure you find a flat, fire-resistant space for your Chimenea away from anything overhanging.

Step 2 – Insert grate

Put the grate inside the Chimenea and ensure the top flue is open.

Step 3 – Start a small fire

Starting with just a few scrunched-up balls of newspaper, and one or two small pieces of kindling. Carefully light your fire using long matches or a long-nosed lighter. Let this fire continue to burn for 60 minutes.

Step 4 – Start a second larger fire

Repeat step 3 to light a fire and add your first wood log to the fire. Don't be tempted to produce a towering inferno with this fire. Add one log at a time and build it slowly. Again, let this fire continue to burn for 60 minutes.

Step 5 – Allow the chimenea to cool

Let the chimenea cool down. NEVER use water to put your chimenea out. The shock of the temperature change can cause cracking.

And now your steel chimenea is cured!

The next time you use your Chimenea, it will be a lot more resilient to cracking.



Scan Here
for product and assembly details

Warranty Conditions

Thank you for purchasing one of our quality Jumbuck products. Please keep your receipt as proof of purchase, as this will authenticate your warranty. Any claim under this warranty must be made within 12 Months of the date of purchase of the product. To make a claim under the warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au for store locations). Bunnings Group Ltd bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof for consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law: our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The warranty excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only and does not apply to commercial applications.

This warranty is given by Bunnings Group Limited

ABN 26 008 672 179, Botanicca 3,
Level 2 East Tower 570 Swan Street,
Burnley, VIC 3121
e-mail: CustomerSupport@bunnings.com.au
PH: 1800 797 586

Bunnings NZ Limited:
PO Box 14436,
Panmure Auckland 1741
email: OnlineEnquiries@bunnings.co.nz
PH: 1800 797 586

RECORD THE FOLLOWING INFORMATION

Attach the copy of the purchase receipt here.

Date of Purchase: _____

Location: _____

Model Name
and Number: _____

Item Number: _____

Receipt Number: _____

The Jumbuck logo is centered within a dark grey rounded rectangle, which is itself set against a larger, light grey semi-circular background at the bottom of the page. The word "jumbuck" is written in a bold, lowercase, sans-serif font.