




ELEMENT




HARDWARE



STEP 1






STEP 2



STEP 3

STEP 4

STEP 5



DISTRIBUTED BY:
Visy Retail Services Pty Ltd (AU): 1300 734 714
Visy Board Limited (NZ): 0800 443 058

For more information please visit:
www.flexistorage.com.au
www.flexistorage.co.nz