

Remsafe Sash Lock



- ✓ Suitable for double hung timber windows
- ✓ Easy DIY installation
- ✓ For increased window security

The Remsafe Sash Lock is supplied with:

- 1 x Lockable Sash Lock body
- 1 x key
- 4 x timber gauge fixing screws

Installation:

1. Choose your desired installation position on your window.
2. Position the receiving body on the fixed window frame. In this position, mark the fixing holes with a pencil.
3. Drill 2 mm pilot holes for the fixing screws and secure the receiving body in position with the screws provided.
4. With the window closed, position the swivel body on the moving window frame in line with the receiving body on the fixed window frame. Ensure the flat edge of the swivel body is aligned closest to the receiving body. In this position, mark the fixing holes with a pencil. Drill 2 mm pilot holes for the fixing screws and secure the swivel body in position with the screws provided.
5. Test the lock for correct positioning.
6. Check the operation of the lock to ensure the swivel arm engages with the receiving body and does not interfere with the opening or closing of the window.
In order to deadlock with the key, the swivel handle must be rotated a full 180 degrees to engage with the receiving body. Check window alignment if unable to engage the lock completely.

Maintenance:

The manufacturer recommends maintenance is carried out on Remsafe products by a licensed tradesman every twelve (12) months. In addition, it is recommended that regular checks (every three to six months) are carried out by the user of each window safety device at the time of operation. Repeated force on a Remsafe Window Locks safety device may lead to general wear and tear and cause screws to become loose.

Consideration must be given to the local environment and maintenance carried out accordingly.

1. All screws must be checked to ensure they have not loosened. Loose screws must be tightened.
2. All lock components must be checked for any signs of corrosion, cracking, or loss of function. Any locks showing signs of corrosion, cracking, or loss of function must be replaced immediately.
3. All components must be checked to ensure against excessive movement. Any lock showing excessive movement must be replaced immediately.
4. If a window is able to be opened greater than 100 mm at any point a licensed tradesperson should be consulted for advice on the most appropriate window restrictor device for each window.

Warning: Window falls may result in injury or death. Falls from heights may still occur through windows with safety devices installed. To prevent falls from heights, climbable elements should be removed from below windows and children should be supervised around open windows.

NEVER LEAVE THE KEY UNATTENDED IN ANY REMSAFE WINDOW LOCKS PRODUCT.

Remsafe Window Locks offer safety solutions for all window types.

**Contact us for orders and enquiries on +61 2 9453 5625, email info@remsafewindowlocks.com.au
or visit www.remsafelock.com.au**