# User Manual
5-in-1 Wireless Charging Station
WLC-4SDNL-559

WHAT'S IN THE BOX:

- Wireless charging station
- 30W wall charger
- USB-C to USB-C charging cable
- User manual

OVERVIEW

Magnetic pad
15W fast-charging for phones

Apple Watch charging pad*
WARNING: Do not charge other wireless charging watches.

Indicator light

USB-C port for powering charging station

Earphones charging pad

USB-A port for charging other devices

LED light switch

LED lights

OPERATION

- Unfold the charging station and put it on a levelled surface.
- Plug the included USB-C charging cable into the back USB-C port. Then connect the other end to the wall charger included.
- Put your phone on the magnetic charging pad. The indicator will turn blue when charging starts.
  ⚠ If the indicator flashes blue, adjust your device's position or remove any foreign objects from the charging area until the indicator stays solid blue.
- Position your Apple Watch on the watch charging pad to charge.
- Place your earphones on the earphones charging pad.

- Use the back USB-A port to connect your USB-A cable and charge other devices.

CHARGING TIPS

- *The wireless watch charging pad charges only Apple Watches.
- Unplug your device when it hits full charge to keep the battery healthy.
- Keep the charger away from direct sunlight and temperatures over 45°C.
- Keep an eye on your device while charging for any issues.
- Wipe charging pads clean with a dry cloth for efficient charging.

WARNINGS

- Keep away from kids; it's not a toy.
- Don't leave devices charging unattended to avoid overheating.
- Avoid charging wet devices to prevent electric shock.
- Keep credit cards, security badges, passports or any magnetic strips away from the charger.

TROUBLESHOOTING

SLOW OR INTERMITTENT CHARGING:

- Check for obstructions or metal behind the device.
- Centre the device on the charging pad.
- Use phone cases thinner than 5mm.

NO CHARGING:

- Restart your device.
- Make sure your device supports wireless charging and try another device.

OVERHEATING:

- Some heat is normal, but if it's too hot, remove the device until it cools down.

SPECIFICATIONS

- Wireless charging output – Phone: 5W/7.5W/10W/15W
- Wireless charging output – Earphones: 5W
- Wireless charging output – Apple Watch: 3W
- USB-A output: 5V⎓2A
- Wall adaptor – input rating: 100-240V~ 50/60Hz 1A
- Wall adaptor – output rating: 5V⎓3A, 9V⎓3A, 12V⎓2.5A, 15V⎓2A, 20V⎓1.5A