



**WINDOWWARE**

# Dual Roller Blind - Boston

## Preparation and Fixing Instructions

**Your pack should consist of the following components:**

- 8 x Screws (Timber)**
- 8 x Plugs (Masonry)**
- 2 x Child Safety Device**
- 2 x Brackets**

### STEP 1 – Select Your Mount & Measure Your Window (FIG.1)

- **FACE MOUNT:** This blind is installed outside the window frame
  - 1) With Architrave; take the external width measurements, including the architrave
  - 2) Without Architrave; take the width of the opening and add an extra 100mm
- **RECESS MOUNT:** This blind is installed inside the window frame; take 3 width measurements to determine if the window is square. If it's not, use the smallest measurement
- Once you have selected your mount, measure the length and width of your window to ensure the correct size blind has been selected for your installation type

### STEP 2 – Side Chain

- Decide if you want the ball chain mechanism to operate from the left hand side or the right\* and insert into the tube on the chosen side
- Insert the pin end into the opposite side (FIG.2)
- Universal Brackets allow for either face or side mount installation. (FIG.3).

### STEP 3 – Bracket Positioning

- Using the bracket as a template, measure and mark the mounting position including the fixing point locations
- Pre-drill pilot holes for screws to prevent any splitting of timber or architrave

### STEP 4 – Fix Brackets

- Secure the brackets to the wall, ceiling, or architrave using screws provided
- Plugs may be required if the blind is being mounted into plaster board or masonry
- Ensure the brackets are installed in the right positions with the hex bracket matching the chain side and the pin matching the other bracket

### STEP 5 – Install Blind

- Once the brackets are secured, lift blind into place by inserting the chain mechanism side into the hex bracket first (FIG. 4)
- For larger size blinds, a two-person lift may be required
- Gently slide the pin into the second bracket until it drops into place

### Repeat for Second Roller

### STEP 6 – Child Safety Devices

Secure the child safety devices (FIG.5) on the wall with the supplied screws (refer to safety warning for more information)

**For easy DIY installation videos, please visit us at [www.smarthp.com.au](http://www.smarthp.com.au)**

FIG. 1




FIG. 2




FIG. 3




FIG. 4





FIG. 5

### Child Safety Device



**How to install?**  
Scan this code to  
view the installation  
video or visit  
[www.smarthp.com.au](http://www.smarthp.com.au)

## **WARRANTY AGAINST DEFECTS**

If a consumer becomes aware of a defect in this product within 24 months of the date of purchase, Windoware, a division of Smart Home Products Pty, Ltd, will repair or replace the product or, at the option of Windoware, refund the purchase price to the consumer. All claims under this warrant must be made in writing addressed to Smart Home Products Australia Pty Ltd at the address below. Any expense in claiming the warranty will be borne by the customer. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund of a major failure and compensation for any other reasonable foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits given by this warranty are in addition to the rights and remedies with may be available to the consumer under any law in relation to goods or services to which this warranty relates.

Smart Home Products Australia Pty Ltd, 39B Naxos Way, VIC 3173, Australia.  
sales@smarthp.com.au