

User Manual



RGB Bluetooth Gaming Soundbar

Thank you for your purchase!

Laser Corporation is 100% Australian owned & operated. To get the most out of your product please read the user manual carefully and keep for future use.

For specific information relating to your product such as Spare Parts, FAQs, Warranty claims, and more, please scan the following QR code:




WHAT'S IN THE BOX

- 1 x RGB Bluetooth Gaming Soundbar
- 1 x Micro USB Charge Cable
- 1 x 3.5mm Audio Cable
- 1 x User Manual

SPECIFICATIONS

Input:	Bluetooth, AUX, USB, and Micro SD Card
USB & Micro SD Card size:	Up to 128GB
Speaker Quantity:	2
Speaker Size:	2"
Speaker Output:	5W
Frequency Range:	260Hz – 18kHz
Sensitivity:	650±50mv
Battery:	2000mAh
Bluetooth:	5.0
Cable:	1M
Input Voltage:	5V
Dimensions:	385 x 64 x 67mm
Weight:	Approx. 610g

CONTROLS



1. **OFF/ON**



Turn speaker on/off.

2.



Plug an AUX cable attached to a source device and the speaker will enter AUX mode automatically.

3.



Plug in a Micro SD card up to 128GB size for playback of MP3 files.

CONTROLS

continued...

4.



DC 5V

Plug the included USB charging cable into a DC 5V USB charging port such as a computer or a USB Power Adapter.

5.



Plug in a USB drive up to 128GB size for playback of MP3 files.

6.




Tap to play or pause music or to answer incoming calls when connected to a smartphone via Bluetooth.

CONTROLS

continued...

7.



Tap to reduce volume or press and hold to skip to previous track.

8.




Tap to increase volume or press and hold to skip to next track.

9.




Tap to change lighting modes or double tap to turn lights off. Press and hold to switch between input sources

BLUETOOTH PAIRING



- Turn the speaker on and it should automatically go into Bluetooth pairing mode if not already connected to another device. If the speaker does not automatically go to Bluetooth mode, press and hold the  button to change input modes on the speaker till you reach Bluetooth mode.
- Search for “SPK-BTSB12” under Bluetooth settings of device you are connecting to e.g. smartphone or tablet.
- You will hear a tone after successful pairing.

TIP: If password is requested during Bluetooth pairing then enter “0000”.

MICRO SD CARD OR USB PLAYBACK

- Plug in a Micro SD Card or USB device via the port on the speaker.
- Up to 128GB drives are supported.
- When connected the speaker will automatically start playing audio from the Micro SD Card or USB device.
- Tap or hold the  and  buttons to skip tracks or to adjust volume.
- Tap  button to play or pause.

HANDS-FREE CALLS

- Turn the speaker on and connect to a smart phone using Bluetooth (see Bluetooth Pairing instructions).
- The speaker can now be used to engage with phone calls from the connected device.
- Tap  to pick up or end a call.
- Press and hold  to reject a call.

TROUBLESHOOTING

No Power:

- Check battery level and charge the speaker if required.
- Try turning on speaker while connected to a power source.
- Try charging the speaker with a USB Wall Adapter (like a smart phone charger) instead of a laptop or computer.
- Use another similar charging cable to recharge the speaker.

TROUBLESHOOTING

continued...

Problems Connecting to Bluetooth:

- Place the speaker next to the smart device you are pairing to e.g., Smartphone.
- Wait up to one minute for “SPK-BTSB12” to appear on your list of available devices.
- If the Bluetooth name “SPK-BTSB12” does not appear on the list of available devices, then try refreshing the list or searching again.

TROUBLESHOOTING

continued...

- Make sure the speaker is in Bluetooth mode (default mode when turning on speaker) before searching on your smart device.
- If the speaker is already connected to another smart device, it will need to be unpaired from that device first or it will need to be out of Bluetooth connection range of that device before it can be connected to another. Please check no one else has connected the device to their own smartphone etc.

TROUBLESHOOTING

continued...

Micro SD Card or USB device not recognised or files not playing:

- Make sure the Micro SD Card or USB device is 128GB or less.
- If the Micro SD Card or USB device is new out of the box, we recommend you format it on a Windows based computer before copying any files to it.
- Make sure to only use MP3 music files copied to the Micro SD Card or USB device. Other formats such as WAV, AAC etc will not work.

WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage. **Please retain your receipt as proof of purchase**

How to make a product warranty claim:

1. Find your receipt with date of purchase. If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
2. Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
3. If your original place of purchase cannot be contacted, please contact Laser with a description of the fault. To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
 - Phone: (02) 9870 3388
 - Email: support@laserco.com.au
 - Online: www.laserco.net/support/warranty and follow the website instructions
 - Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia
4. Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you without the need to return the product.
5. If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment. If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
6. Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more
helpful guides
visit us at



LASER
www.youtube.com/LasercoAu

www.laserco.com.au



SCAN ME