

# ozito

## HOME 12VOLT

# CORDLESS GLUE GUN


### 12V Lithium Ion

## INSTRUCTION MANUAL


### SPECIFICATIONS

Input:	12V
Glue Stick Size	Ø7.2 x 190mm
Heating Time:	10 sec
Max Heating Temp:	170°C
Weight:	0.24kg


[ozito.com.au](http://ozito.com.au)



### WHAT'S IN THE BOX



Cordless Glue Gun



3 x Glue Stick

# 3

## YEAR REPLACEMENT WARRANTY

ZLGG-012

## WARRANTY

IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO YOUR NEAREST BUNNINGS WAREHOUSE WITH YOUR BUNNINGS REGISTER RECEIPT. PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

Australia 1800 069 486

New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you at law.

Our goods come with guarantees that cannot be excluded at law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Generally you will be responsible for all costs associated with a claim under this warranty, however, where you have suffered any additional direct loss as a result of a defective product you may be able to claim such expenses by contacting our customer service helpline above.

### 3 YEAR REPLACEMENT WARRANTY

Your product is guaranteed for a period of **36 months from the original date of purchase** and is intended for DIY (Do It Yourself) use only. If a product is defective it will be replaced in accordance with the terms of this warranty. **Lithium Ion batteries and chargers are covered by a 12 month warranty.** Warranty excludes consumable parts, for example: accessories etc.

### WARNING


**The following actions will result in the warranty being void.**

- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- Failure to perform maintenance as set out within the instruction manual.
- If the tool is disassembled or tampered with in any way.
- Professional, industrial or high frequency use.

# KNOW YOUR PRODUCT


## CORDLESS GLUE GUN

- |                           |                        |
|---------------------------|------------------------|
| 1 Protective Nozzle Cover | 5 Battery Seating      |
| 2 Trigger Flow Control    | 6 Glue Stick Entry     |
| 3 On / Off Button         | 7 LED Indicator Lights |
| 4 Glue Display            |                        |



## ACCESSORIES

- 8 Glue Stick x 3 ( Ø7.2mm x 190mm )



## BATTERY & CHARGER

This tool is compatible with all batteries and chargers from the Ozito Home-12volt range.

## ONLINE MANUAL

Scan this QR Code with your mobile device to take you to the online manual.




# SETUP & PREPARATION

## 1. FITTING THE BATTERY


### Installing the Battery Pack

1. Slide the battery into the Glue Gun base until it clicks into place.



### Removing the Battery Pack

1. Hold down the battery release button and then slide the battery out.



**3** YEAR REPLACEMENT WARRANTY

# OPERATION


## 2. LOADING THE GLUE STICK




**WARNING!** ENSURE THE TOOL IS SWITCHED OFF AND ALLOWED TO COOL DOWN BEFORE PERFORMING ANY OF THE FOLLOWING TASKS.

### Installing the Glue Stick

- 1 Insert the glue stick into the glue stick entry and slide down gently.



- 2 Squeeze the trigger flow control multiple times to allow the glue stick to be pushed down.




## 3. SWITCHING THE GLUE GUN ON


### Switching the Glue Gun On

- 1 Hold the on/off switch down for roughly 3 seconds to start the glue gun.


**Note:** A LED light will illuminate when switched on.



- 2 The first indicator light will glow red to indicate the glue gun is on.



- 3 The second indicator light will then glow green after 10 seconds indicating the glue gun is ready to use.




**Note:** Allow the glue gun to heat up before you start operating.



**WARNING!** THE GLUE GUN NOZZLE AND HEATED GLUE GUN BECOME HOT WHILE IN USE. IN THE EVENT OF ACCIDENTAL SKIN CONTACT WITH HOT GLUE, RUN UNDER COLD WATER IMMEDIATELY.

### Switching the Glue Gun Off

- 1 Press the on/off switch to switch off. All LED lights will turn off.




**CAUTION!** THE PROTECTIVE NOZZLE WILL REMAIN HOT FOR A FEW MINUTES. DO NOT STORE THE GLUE GUN DIRECTLY AFTER USE. ALLOW THE NOZZLE TO COOL AND THE GLUE TO SOLIDIFY.

## 4. CONTROLS

### Trigger Flow Control


The flow rate of the glue is dependent on how much pressure is applied to the trigger flow control.

- 1 Squeeze the trigger flow control to release the glue.




**Tip:** Ensure the glue sticks are heated fully to allow an even flow of glue.


- 2 Press the surfaces to be glued together within 15 seconds for a strong bond.



- 3 To stop the flow of glue from the gun, release the trigger flow control.



**WARNING!** DO NOT ALLOW HOT GLUE TO COME IN CONTACT WITH PRODUCT HOUSING DURING USE.







## MAINTENANCE

- When not in use, the glue gun should be stored in a dry, frost free location, keep out of children's reach.
- If the housing of the glue gun requires cleaning, do not use solvents. Use of a cloth only is recommended. Never immerse any part of the glue gun into liquid.

**Note:** Ozito Industries will not be responsible for any damage or injuries caused by repair of the glue gun by an unauthorised person or by mishandling.

## DESCRIPTION OF SYMBOLS

<b>V</b>	Volts	<b>Hz</b>	Hertz
<b>ac/~</b>	Alternating current	<b>W</b>	Watts
<b>dc/---</b>	Direct current	<b>Ø</b>	Diameter
<b>mA</b>	Milliamperes	<b>Ah</b>	Amp hour
	Regulator compliance mark (RCM)		Double insulated
	Warning		Read instruction manual

## TROUBLESHOOTING

### LED lights do not illuminate on charger

Check the charging adaptor is securely plugged into the wall outlet.

Check the battery is firmly connected to the charging cradle.

Check that the charging jack is securely connected to the charging cradle.

### The battery has a short run time

Ensure the battery is properly charged. It will take 4-5 charging cycles before the battery reaches optimum charge and run time.

### Glue gun will not turn on

Ensure you hold the on/off switch down until the LED light illuminates indicating it is heating up.

### No glue is flowing out of the nozzle

Ensure the glue gun is switched on and has been allowed time to heat the glue sticks completely.

### Glue Gun has cut out during use

The glue gun will automatically switch off after 5 minutes of inactivity to ensure the glue gun is not left off accidentally. Simply press the on/off button for 2 seconds to switch the glue gun back on.

## SPARE PARTS

**Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse.**

**For further information, or any parts not listed here, visit [www.ozito.com.au](http://www.ozito.com.au) or contact Ozito Customer Service:**

**Australia 1800 069 486**

**New Zealand 0508 069 486**

**E-mail: [enquiries@ozito.com.au](mailto:enquiries@ozito.com.au)**

## CARING FOR THE ENVIRONMENT




Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

# ELECTRICAL SAFETY

 **WARNING!** When using mains-powered tools, basic safety precautions, including the following, should always be followed to reduce risk of fire, electric shock, personal injury and material damage.

Read the whole manual carefully and make sure you know how to switch the tool off in an emergency, before operating the tool.

Save these instructions and other documents supplied with this tool for future reference.

The manufacturer cannot accept any liability for damage or accidents which arise due to a failure to follow these instructions and the safety information.

This product has been designed for 230V and 240V only. Always check that the power supply corresponds to the voltage on the rating plate.

Note: The supply of 230V and 240V is interchangeable for Australia and New Zealand.



This tool's charger is double insulated therefore no earth wire is required.

The power supply for this product should be protected by a residual current device (rated at 30mA or less). A residual current device reduces the risk of electric shock.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.


**Note:** Double insulation does not take the place of normal safety precautions when operating this tool. The insulation system is for added protection against injury resulting from a possible electrical insulation failure within the tool.

## Using an Extension Lead

Always use an approved extension lead suitable for the power input of this tool. Before use, inspect the extension lead for signs of damage, wear and ageing. Replace the extension lead if damaged or defective.

When using an extension lead on a reel, always unwind the lead completely. Use of an extension lead not suitable for the power input of the tool or which is damaged or defective may result in a risk of fire and electric shock.

# GENERAL POWER TOOL SAFETY WARNINGS

 **WARNING!** Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. **Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.**

## 1. Work area safety

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

## 2. Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

## 3. Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- Use personal protective equipment. Always wear eye protection.** Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.


## 4. Power tool use and care

- Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

## 5. Service

- Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

# GLUE GUN SAFETY WARNINGS

 **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

**Recommendations for the use of a residual current device** with a rated residual current of 30mA or less.

**Ensure the area is well ventilated.**

## Safety Tips

- Do not touch hot glue.
- Do not remove the glue from skin in the event of accidental contact. Immediately run cold water over and seek medical advice.
- Do not leave glue gun unattended while in use or directly after use.
- Do not touch the nozzle end of the gun while in use or directly after use.
- Do not inhale vapours generated while in use.
- Do not attempt to feed any other materials through the glue gun, eg. crayons, sealants, candles etc.
- Do not apply to the same place for a long time

- Do not use in presence of an explosive atmosphere
- Be aware that heat may be conducted to combustible materials that are out of sight
- Place the appliance on its stand after use and allow it to cool down before storage
- Do not leave the appliance unattended when it is switched on

The appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.

Young children should be supervised to ensure that they do not play with the appliance.

**This tool contains a lithium ion battery.** For user safety:

- Do not use or store tool in temperatures exceeding 50°C
- Do not put tool in the rubbish
- Do not incinerate
- Do not get battery wet, do not expose tool to rain.