



## Smoke Alarm Troubleshooting Guide

### PROBLEM

### SOLUTION

Smoke alarm does not sound when testing.

- Power source is depleted. Replace the smoke alarm.

The alarm chirps with red LED flashing once every 40 seconds.

- Power source is depleted. Replace the smoke alarm.

The alarm chirps every 40 seconds and 16 seconds after each chirp, the red light flashes once. This is fault mode.

- Clean smoke alarm. Refer to the **Maintenance and Cleaning** section in the User Guide (link below).
- Replace the smoke alarm if the problem persists.

Smoke alarm sounds unwanted alarms intermittently or when residents are cooking, taking showers, etc.

- Press and hold in Hush button to silence the alarm.
- Vacuum the alarm. Refer to the **Maintenance and Cleaning** section in the User Guide (link below).
- Smoke alarm may be incorrectly located. Move smoke alarm to new location. See **Installation** section in the User Guide (link below).

The alarm sounds different to normal.

- Clean smoke alarm. Refer to the **Maintenance and Cleaning** section in the User Guide (link below).
- If there are still failures during warranty, you can return to your retailer.
- If the unit is out of warranty, replace it with a new alarm.

[Click here for User Guide](#)

or browse to <https://newfield.help/nv208s>