



Stainless Steel Counter Refrigerators/Freezers
Instruction manual



Model:

**G596-A/G597-A/G598-A/G599-A/G600-A/
DL914-A/DL915-A/DL916-A/DL917-A**

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Wiring Regulations
 - Building Regulations
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use this appliance to store medical supplies.
- DO NOT use electrical appliances inside the appliance (e.g. heaters, ice cream makers etc.)
- DO NOT stand or support yourself on the base, drawers or doors.
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- Bottles that contain a high percentage of alcohol must be sealed and placed vertically in the refrigerator.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the unit before cleaning.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a POLAR agent or a recommended qualified technician in order to avoid a hazard.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Polar recommend that this appliance is PAT tested on an annual basis to ensure the product remains safe.



Caution Risk of Fire

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.



Warning: Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.

- **Warning:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Warning:** Do not damage the refrigerant circuit.
- **Warning:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are the type recommended by the manufacturer.

Product Description

G596-A - POLAR 282 litre 2 Door Counter Refrigerator

G597-A - POLAR 417 litre 3 Door Counter Refrigerator

G598-A - POLAR 563 litre 4 Door Counter Refrigerator

G599-A - POLAR 282 litre 2 Door Counter Freezer

G600-A - POLAR 417 litre 3 Door Counter Freezer

DL914-A - Polar Counter GN REFRIGERATOR - 2 Doors 700mm with upstand

DL915-A - Polar Counter GN REFRIGERATOR - 3 Doors 700mm with upstand

DL916-A - Polar Counter GN FREEZER - 2 Doors 700mm with upstand

DL917-A - Polar Counter GN FREEZER - 3 Doors 700mm with upstand

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your POLAR product.

Pack Contents

The following is included:

- POLAR Refrigerator or Freezer
- Shelf guide (2 per door)
- Shelf (1 per door)
- Instruction manual

POLAR prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your POLAR dealer immediately.

Installation



Note: If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.

1. Remove the appliance from the packaging. Make sure that all protective plastic film and coatings are thoroughly removed from all surfaces.
2. Maintain a distance of 20cm (7 inches) between the unit and walls or other objects for ventilation. **NEVER LOCATE NEXT TO OR NEAR A HEAT SOURCE.**



Note: Before using the appliance for the first time, clean the shelves and interior with soapy water.

3. Set the brakes on the castors to keep the appliance in position.

Fitting the Shelves & Floor Guards

1. Place one set of shelf guides on either side of the cabinet at the desired height.
2. Slide the shelf into place.
3. Repeat for the remaining shelves.
4. Place the floor guards on the floor of the

cabinet, ensuring the flat side is clear of the floor.



Note: This is vital for ensuring correct drainage of condensation.

Operation

Storing Food


To get the best results from your POLAR appliance, follow these instructions:

- Only store foodstuffs in the appliance when it has reached the correct operating temperature.
- Do not place uncovered hot food or liquid inside the appliance.
- Wrap or cover food where possible.
- Do not obstruct the fans inside the appliance.
- Avoid opening the doors for prolonged periods of time.

Turn On

1. Ensure the power switch is set to [O] and turn on at the socket.
2. Switch on the Power [I]. The current temperature within the appliance is displayed.

Control Panel



Set the Operating Temperature

1. Hold the **SET** button for 3 seconds. The value of the current set point will be displayed.
2. Press the ▲ or ▼ buttons to display the required temperature.
3. Press the **SET** button to store the temperature.

Manual Defrost

- The appliance will automatically run a defrost cycle every six hours.
- **To manually defrost the appliance:** Press and hold the defrost button "aux" for 2 seconds to begin a manual defrost. The defrost light illuminates.

Cleaning, Care & Maintenance



Defrost appliance at least every 3 months, more often if required.

Switch off and disconnect from the power supply before cleaning.

- Clean the interior of the appliance as often as possible.
- Do not use abrasive cleaning agents. These can leave harmful residues.
- Clean the door seal with warm soapy water.
- Always wipe dry after cleaning.
- Do not allow water used in cleaning to run through the drain hole into the evaporation pan.
- Take care when cleaning the rear of the appliance. Sharp edges can cut.
- A POLAR agent or qualified technician must carry out repairs if required.

Stainless Steel Care

To maintain the stainless steel exterior of your Polar item, please consider the following information:

Never:

- Use abrasive Scourers or scrubbing pads, etc.
- Use Chlorinated or acidic detergents
- Allow anything e.g. food, dirt, cleaning chemicals to remain on the surface for longer than necessary, clean them off right away.
- Allow the surface to remain wet.


Do:

- Clean often.
- Use soft Cloths or plastic Scourers.
- Rub with the grain of the metal, rather than across it.
- Use detergents and polish designed for cleaning Stainless Steel.
- Ensure that the cleaning products are washed off fully and that the steel is left dry.

Routine Maintenance

Condenser Cleaning

- The condenser is part of the refrigeration system. The condenser requires monthly cleaning.
- Always disconnect power supply before carrying out Routine Maintenance.
- Failure to clean the condenser will reduce the performance and life of your Polar unit and may invalidate your warranty
- The condenser is located behind the service door on the right-hand side of the refrigeration cabinet.
- These models have a removable filter which can be cleaned with a vacuum cleaner.



Troubleshooting

If your POLAR appliance develops a fault, please check the following table before making a call to the Helpline or your POLAR dealer.

Fault	Probable Cause	Solution
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call POLAR agent or qualified Technician
	Fuse in the plug has blown	Replace the fuse
	Power supply	Check power supply
	Internal wiring fault	Call POLAR agent or qualified Technician
The appliance turns on, but the temperature is too high/low	Too much ice on the evaporator	Defrost the appliance
	Condenser blocked with dust	Clean the Condenser
	Doors are not shut properly	Check doors are shut and seals are not damaged
	Appliance is located near a heat source or air flow to the condenser is being interrupted	Move the refrigerator to a more suitable location
	Ambient temperature is too high	Increase ventilation or move appliance to a cooler position
	Unsuitable foodstuffs are being stored in the appliance	Remove any excessive hot foodstuffs or blockages to the fan
	Appliance is overloaded	Reduce the amount of food stored in the appliance
The appliance is leaking water	The appliance is not properly levelled	Adjust the screw feet to level the appliance (if applicable)
	The discharge outlet is blocked	Clear the discharge outlet
	Movement of water to the drain is obstructed	Clear the floor of the appliance (if applicable)
	The water container is damaged	Call POLAR agent or qualified Technician
	The drip tray is overflowing	Empty the drip tray (if applicable)
The appliance is unusually loud	Loose nut/screw	Check and tighten all nuts and screws
	The appliance has not been installed in a level or stable position	Check installation position and change if necessary

Technical Specifications

Model	Voltage	Power	Current	Temperature Range	Capacity (litres)
G596-A	230V 50Hz	350W	1.95A	-2°C to 8°C	282
G597-A	230V 50Hz	350W	1.95A	-2°C to 8°C	417
G598-A	230V 50Hz	350W	1.95A	-2°C to 8°C	563
G599-A	230V 50Hz	750W	3.5A	-10°C to -20°C	282
G600-A	230V 50Hz	750W	3.55A	-10°C to -20°C	417
DL914-A	230V 50Hz	350W	1.95A	-2°C to 8°C	282
DL915-A	230V 50Hz	350W	1.95A	-2°C to 8°C	417
DL916-A	230V 50Hz	750W	3.5A	-10°C to -20°C	282
DL917-A	230V 50Hz	750W	3.5A	-10°C to -20°C	417

Model	Refrigerant	Dimensions H x W x D mm	Weight (kg)
G596-A	R290 95g	860 x 1360 x 700	98
G597-A	R290 95g	860 x 1795 x 700	134
G598-A	R290 95g	860 x 2230 x 700	153
G599-A	R290 90g	860 x 1360 x 700	98
G600-A	R290 90g	860 x 1795 x 700	136
DL914-A	R600a 95g	960 x 1360 x 700	108
DL915-A	R600a 95g	960 x 1795 x 700	139
DL916-A	R290 90g	960 x 1360 x 700	108
DL917-A	R290 90g	960 x 1795 x 700	143

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

The appliances must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

POLAR parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

POLAR products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of POLAR.

Every effort is made to ensure all details are correct at the time of going to press, however, POLAR reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

Equipment Type Counter Gastro Refrigerator 2 Doors
Counter GN refrigerator - 2 Doors 700mm with upstand
Counter Gastro Refrigerator 3 Doors
Counter GN refrigerator - 3 Doors 700mm with upstand
Counter Gastro Freezer 2 Doors
Counter GN Freezer - 2 Doors 700mm with upstand
Counter Gastro Freezer 3 Doors
Counter GN Freezer - 3 Doors 700mm with upstand
Counter Gastro Refrigerator 4 Doors

Model G596-A
DL914-A
G597-A
DL915-A
G598-A
DL916-A
G599-A
DL917-A
G600-A

Legislation Electrical Safety
Electromagnetic Compatibility

Standards AS/NZS60335-1:2010 +A1:2013
AS/NZS60335-2-89:2010 +A1:2012
EN55014-1 :2006 +A1:2009 +A2:2011
EN55014-2:1997 +A1:2001 +A2:2008
EN61000-3-2:2014
EN61000-3-3:2013

Producer Name Polar

Producer Address 15 Badgally Road,
Campbelltown,
NSW2560

I, the undersigned, hereby declare that the equipment specified above conforms to the above Legislation and Standard(s).

Date 1st August 2017

Signature 

Full Name Ashley Hooper

Position Technical & Quality Manager/ Responsible Supplier



<http://www.polar-refrigerator.com/> 

G596-A_G600-A_DL914-A_DL917-A_A5_v6_20190429