Mondella

PLUMBERS INSTALLATION GUIDE SHOWER / BATH MIXER

INSTALLATION

- 1. Ensure the mixer is in the closed position during the installation process. Also make sure the supply lines are free of foreign materials that could damage the ceramic cartridge.
- 2. When mounting the mixer on the wall frame, take note dimensions shown in diagram A.
- 3. Connect water supply to the inlets as shown in diagram B.
- 4. The mixer must be installed with the outlet vertical to ensure correct handle orientation.
- 5. On completion of the installation, slide the wall plate over the mixer body and press firmly against the wall.
- 6. Fit the handle to the cartridge by locking it in with the grub screw and allen key provided.
 NOTE: Caution must be taken when pressure testing the system, as back pressure on the outlet side (riser) may cause the ceramic disc to separate.

The following is the recommended procedure for pressure testing the mixer:

- 1. System to be flushed of all foreign materials before pressure testing the mixer for at least 30 seconds.
- 2. Pressure test system, inspect for leaks.
- 3. Set mixer to the off position and depressurise the system (both inlet sides and the outlet riser side).

NOTE: Do not pressurise the outlet side again or leave in a pressurised state.

WORKING SPECIFICATIONS

In accordance with Australian standards requirements it is recommended that all tapware be installed by a licensed plumber. Please refer to warranty card for service agreement.

NOTE: It is not recommended to use this mixer with the following set up -


- · Longer than standard length pipe running from outlet
- Shower offset to the rose
- Rose on an alternate wall

Any of the above may cause reverse water hammering.

- Hot and cold water inlet pressures should be equal
- Inlet pressure range: 150-500kPa

NOTE: New Regulation - 500kPa maximum operating pressure at any outlet within a building. (Ref. AS/NZS 3500.1-2015, Clause 3.3.4)

- All pipework must the thoroughly flushed prior to installation.
- This mixer may not be suitable for connection to some of the following products: instantaneous gas water heaters, tempering valves, solar water heaters and thermostatic mixing valves. Check with the manufacturers of these products.
- Not recommended for gravity feed systems, tank water systems or bore water systems.



CARING FOR YOUR PRODUCT

- Under no circumstances should you install tapware using acetone silicones.
- Never use harsh detergents or abrasive cleaners, as these will scratch the surface. Using a soft dry cloth or a soft cloth with warm soapy water is recommended.
- Where your tapware remains dry in use, a soft cloth can be used to remove surface dust.

 Alternatively, a wipe over with warm soapy water is all that is required to maintain the finish in perfect condition for a lifetime of use.
- Use of wax based furniture cream should be avoided as these can result in a build up of deposits, which could detract from the appearance.
- Do not use undue pressure and wipe in one direction only.