




Figure 1

1. Loosen the set screw on the accessory, using the 2.5mm hex key provided, and remove the backing plate.
2. Position the accessory against the wall, ensure that the accessory is level and mark outline with pencil.




Figure 2

Position the backing plate flat side down on the wall and mark holes with pencil.




Figure 3

Mount to concrete or drywall:

Pre-drill holes on the wall to fit wall anchors. (6mm drill bit recommended).

Insert wall anchors into the wall.

Position backing plate flat side down over the anchors and install screws.

Mount to wood:

If installing on wood surface, use wood screws. (NO anchors required).




Figure 4

Slide the accessory onto the backing plate and tighten the set screw the using 2.5mm hex key provided.

PRODUCT CARE INSTRUCTIONS:

- Avoid harsh detergents and acetone silicones when installing as well as abrasive cleaners, as they can scratch the surface or damage the product
- Clean using a soft, dry cloth or a soft cloth with warm

soapy water

- In coastal areas, product surface should not be exposed to direct ocean salt spray
- Ensure product surfaces are cleaned regularly.

THANK YOU FOR PURCHASING ONE OF OUR QUALITY MONDELLA PRODUCTS.

Please keep your receipt as proof of purchase, as this will authenticate your warranty. Any claim under this warranty must be made within the warranty period from date of purchase of the product. To make a claim under the warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au or www.bunnings.co.nz for store locations) or contact Blutide Pty Ltd. Blutide Pty Ltd bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof to Blutide Pty Ltd for consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law: our goods come with guarantees which cannot be

excluded under the Australian Consumer Law (ACL) or the New Zealand Consumer Guarantees Act (CGA). You are entitled to replacement or refund for a major failure and to compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The warranty excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Blutide Pty Ltd, ABN 39 669 825 003, P.O.Box 535, Elsternwick, Vic, Australia, 3185, phone number: 1300 900 213, service@blutide.com.

WARRANTY PERIODS

MIXERS, TAPWARE, TOILETS & SHOWERS

- 10 years replacement product or parts
- 1 year replacement product or parts and labour

The warranty covers domestic use only and does not apply to commercial applications.

AFTERMARKET SERVICE PROCEDURE

Please email service@blutide.com and include the following information: proof of purchase, item number and product description, installing person's name and contact details.

PRODUCT WARRANTY

WARRANTY SHALL BE VOID FOR THE FOLLOWING REASONS:

- Inability to provide proof of purchase.
- Products not installed in accordance with the manufacturer's installation instructions.
- Products used for incorrect applications.
- Service or repairs with non-standard replacement parts previously undertaken without written approval.
- Damage to finishes by adhesive, sealant etc.
- Damage to product and/or components due to exposure to caustic or corrosive substances or environments.
- Any damage which arises from installation or post-installation use.