




1. Floor boards & sheet flooring cut out: 200mm x 200mm, Concrete cut out: 300mm x 300mm.




2. Check that the shower base sits level.




3. Test the water flow.



4. Cover and protect the shower base until shower screen & tiles are installed.



5. Silicone the bottom edge of the shower wall to the base before the screen is fitted.



Make sure there is clearance between the shower base and the wall stud to allow for movement

### Important

- Prior to installation, thoroughly inspect product and components for transport damage and manufacturing defects. Warranty claims will not be honoured if installed with pre-existing defects.
- Local or state regulations may require some work to be performed by a licensed tradesperson. Check these regulations prior to installation.
- This product must be installed in accordance with local, state or national regulations.
- It is recommended installation practice to check the edge of the base into the wall by the width of the tiling flange in order to provide a leak free joint with the wall cladding material (see Figure A).

### Installation

1. Floor boards or sheet flooring must cover the entire underside of the base. Cut hole through floor no greater than 200mm x 200mm (concrete should be 300mm x 300mm).
2. **Level substrate**  
Spread a minimum 10mm of cement based tile adhesive on the floor, slightly wider than the base, using a 12mm notched trowel. Ensure the total base area is fully supported.  
**Non-level substrate**  
Spread a minimum 10mm thick mortar bed of 4:1 washed sand/cement over the area where base is to be installed then trowel off level. Ensure the total base area is fully supported.
3. It is imperative to test for water run off to the waste outlet prior to lining shower walls. This will ensure base is draining correctly. Failure to do so will void the warranty.
4. It is recommended that you cover and protect the base until first use.
5. Silicone the bottom edges of the shower wall to the base before the screen is fitted.

### Cleaning

- Clean with a soft cloth using warm soapy water or mild household detergent.
- Do not use harsh chemicals, abrasive cleaners or scouring pads.
- Avoid using window cleaning sprays or other cleaners with ammonia compounds.
- Hair dyes and colouring shampoos may cause staining. Staining is not covered by warranty.
- If accidental abrasions occur the surface brilliance can be restored by polishing with silicone-based polish.

### Warranty

See warranty card for further warranty information.

Warranty shall be void for the following reasons:

- Water temperature from tap/shower exceeding 55°C
- Shower base and/or components not installed by a licensed tradesperson or not installed to relevant local, state or national regulations
- Shower base installed using tile adhesive on a non-level substrate
- Shower base installed on a non-level substrate with anything other than 4:1 washed sand/cement
- Cracking as a result of not allowing clearance for movement\*

\*Shower bases enclosed between 3 walls can crack due to thermal expansion of the base where adequate allowance has not been given between walls.

### Shower Tile Performance (Rococo Polymarble Shower Bases)

The primary function of the shower tile is to make the base aesthetically pleasing. The shower tile can stay as a drain cover while the shower is in use if the shower complies with the following:

1. The shower head has a WELS rating of 3 or 4 star with a maximum output of 9L/min.  
Note—Flow controller should not be removed.
2. A water trap must be located more than 1m from the shower base.
3. Plumbing must be adequately vented.

Failure to comply with these points will result in the tile restricting the flow of water and filling the base. In this case, the shower base will adequately drain water however the shower tile will need to be removed.