

# Marquee Cafe Blind Preparation and Fixing Instructions

Our easy DIY cafe blinds instructions provides a simple and quick installation so you can enjoy your new cafe blinds in your outdoor living space today!

Ensure you follow all care and installation instructions to maintain the longevity of your cafe blinds.


**Note: Roll up blinds in high winds to avoid damage.** Whilst we guarantee our blinds will withstand tough conditions, we do advise that you roll your blinds up if a storm is approaching. This will ensure to minimise movement in the wind. If blinds are left down and damaged by high winds the warranty will be void.

Your cafe blinds have been rolled up for packaging. You may need to leave the blinds down for several days to allow material to settle.



Your pack should consist of the following components:

**Blind installation components:**



**Cafe blind installation:**

**Cafe blind installation instructions:**

## 1. Select your mount

Blind should always be fixed to a solid structure, ie. cross beams, concrete or brick. To attach blind you will need to measure and drill holes in cross beam in line with holes in head rail of blind.

Choose your mount, there are two ways to mount the cafe blind to a structure:

### Face mount (Fig. 1):

This mount is for installing your cafe blind to the front of the crossbeam or mounting structure.

### Recess mount (Fig. 2):

This mount is for installing your cafe blind to the underside of the crossbeam or mounting structure.

Fig. 1





Fig. 2




## 2. Mark measurements and secure head rail.

To attach blind you will need to measure and drill holes in cross beam in line with holes in head rail of blind.

1. Mark your beam in accordance to your measurement with holes in headrail and drill 5mm holes into structure.
2. Simply line-up head rail holes with holes in cross beam and fix with coach bolts provided.

**Note:** An easy way to do this is to nail the blind in desired position through outer holes, drill and screw coach bolts into inner holes. Remove nails and repeat with outer holes.



## 3. Settle and trim.


Once blind has settled (allow approx. 10 days), the bottom flap may be trimmed to reduce scrapping (if necessary).

1. Rule proportion of flap to be trimmed.
2. Using a sharp craft knife, cut skirting straight to suit your application.

**Note:** Bottom tab can provide extra draft & debris protection if left at floor level length.

## 4. Additional blind support

For additional support of blind, base anchor plates (included) can be fitted to tighten the blind to the ground.




## Additional fixing

For a more secure fitting you can attach blind to side post using wall anchor. Wall anchors are not included in pack, they can be purchased separately in 2.1 metre lengths (to suit 2.4cm drop).

**Note:** You need a wall anchor on each side of blind for a more secure installation.

### How to install wall anchor

1. Measure and mark where wall anchor needs to sit so channel is in line with roped edge of blind.
2. Mark wall anchor and post at intervals of approximately every 500mm and drill a hole. Wall anchor may need to be cut with hacksaw to fit application.
3. Pass roped edge of blind through channel of wall anchor at both sides.
4. Fix wall anchor to post by lining up guide marks and using appropriate screws.
5. To roll up blind simply unzip each side of blind and pull on cord to roll-up blind.



## Rope configuration:

Your blind will come with the ropes gathered at the head rail (please see FIG.1).

Make sure ropes are positioned so they form a loop at the bottom of the blind (please see FIG. 2).

**Note:** Rope must be positioned behind and in front of the blind.

It is recommended the blind is rolled by hand initially. This will create memory in the fabric to allow easier rolling in the future.

Fig.1





Fig.2



# WARNING:

To avoid creating a possible strangulation hazard for children, the corded internal window covering must be installed in such a way that a loose cord cannot form a loop 220mm or longer at a height of less than 1600mm above floor level.

A cord guide may be installed lower than 1600mm above the floor level if the cord is sufficiently secured or tensioned to prevent a loop 220mm or longer from being formed.

If a cord guide is installed lower than 1600mm above floor level it must be designed to prevent a child from being able to remove the cord.

If a cleat is used to secure the cord, it must be at least 1600mm above the floor level because a child is capable of unwinding a cord from a cleat.

## PRODUCT WARRANTY AND LIMITATION OF LIABILITY

### Warranty

Smart Home Products (SHP) manufactures various fabric components (Products) of Marquee Cafe Blinds and SHP brands.

Subject to the conditions set out in a Specific Product Warranty, which are generally summarised in this document, SHP warrants to the owner of a Smart Home Product(s), that the Product is free from manufacturing defects. If a Product with a manufacturing defect becomes apparent and is reported to SHP in accordance with the instructions set out in the Warranty, then SHP will provide a remedy to you in accordance with the Warranty.

The Warranty is valid in respect of your Smart Home Product purchased after 1 January 2017, for the term specified in your Specific Product Warranty. The Warranty is in effect only for Products manufactured by SHP. For components of the SHP Product not manufactured by SHP, the warranty applicable to such components shall be the current warranty provided by the manufacturer of those components. SHP shall be under no liability whatsoever, except for the express conditions as detailed and stipulated in the manufacturer's warranty.

### EXCLUSIVE REMEDY

For any portion of the Product that does not perform as a result of a manufacturing defect, SHP will provide you with a replacement Product (or part thereof). Decisions as to the extent of repair or replacement required will be made solely by SHP. The remedy under your Specific Product Warranty is available only for that portion of the Product actually exhibiting defects at the relevant time. The replacement Product (or part thereof), as well as any remaining original Product, will be warranted only for the remainder of the original Warranty Period.

### EXCLUSIONS FROM COVERAGE

1. SHP will NOT be liable for and Specific Product Warranties generally do NOT cover:
  - damages to the Product resulting from anything other than an inherent manufacturing defect in the Product, including without limitation damage caused or contributed to by:
  - installation, erection, application or use of the Product not being in strict accordance with SHP's instructions, guidelines or warnings;
  - improper transport, storage or handling of the Product, or use of the Product for purposes other than that for which the Product was designed or intended;
  - any variation, alteration or modification to the Product in any way unless approved in writing by SHP;
  - far wear and tear, and extraordinary causes beyond far wear and tear, including weather conditions, force majeure events and natural disasters, such as floods, lightning, hail, windstorms, tornadoes and earthquakes;
  - your use of components other than genuine SHP parts or any work performed on the Smart Home Product by companies or persons that have not been authorised by SHP;
  - exposure of the Product to damaging substances, such as chemicals, oils or solvents, or to mechanical friction, scratching, abrasion, chipping or any other impact;
  - placing the Product near an open flame, or too close to any heat source;
  - reinforcing the Product beyond its tear and tensile capabilities;
  - any act or omission of any person other than SHP, including misuse, neglect, accident or abuse;
  - movement or defects in the building, walls, foundation, or any other material or structure used as a base over which the Product is installed;
  - the continued use of your Product after any defect becomes apparent or would have become apparent to a reasonably prudent operator or user.
2. Any variations or defects in appearance, colour or shade or defects which are of a purely aesthetic or cosmetic nature, including any surface corrosion on aluminium products, or colour fading of the Product, or any deterioration in the chemical composition of the fabric of the Product for any reason including exposure to ultra-violet rays.
3. Any travel or accommodation expenses or any labour and other costs involved with the removal or repair of the defective Product, or on-site assembly or installation of the replacement Product.
4. Compensation for any delay in either replacing or repairing the Product or in properly assessing a claim under your Warranty.

### PURCHASER'S RESPONSIBILITIES

The original purchaser of the Product (Purchaser) must inspect the Product on delivery and shall within 30 days of delivery notify SHP of any alleged defect, damage or failure to comply with the description or quote. The Purchaser shall afford SHP an opportunity to inspect the Product within a reasonable time following delivery if the Purchaser believes the Product is defective in any way. If the Purchaser fails to comply with these requirements, the Product shall be conclusively presumed to be accepted by the Purchaser and free from any defect or damage.

Where SHP has agreed in writing that the Purchaser is entitled to reject a Product, SHP's liability is limited to either (at SHP's discretion) replacing the Product or repairing the Product provided that:
 

- the Purchaser has complied with the provisions of the Warranty;
- if requested by SHP, the Products are returned at the Purchaser's cost within 30 days of the delivery date or the timeframe otherwise specified by SHP;
- SHP will not be liable for Products which have not been stored or used in a proper manner;
- the Product is returned in the condition in which they were delivered and with all retail packaging material, brochures and instruction material in as new condition as is reasonably possible in the circumstances.

The Purchaser also has the sole responsibility to determine whether the Products comply with applicable codes and standards for the intended use. Building codes, permits, set back requirements, and property line issues are the property owner's responsibility to handle as necessary. SHP is held harmless from any disputes, litigation, disagreements, payments, or any problems that may arise, regarding faulty installation, property disagreements, permits, set back requirements, or any other problems regarding installation of the Products.

**IMPORTANT NOTE:** While all care is taken in the production of DIY product guides all product guides are provided as an indicative installation guide only. SHP is not liable or responsible for the outcome of any Products installed using these guides.

Where you are not the original Purchaser of the Product (for instance where you purchase the Product from an original Purchaser), the Product will be warranted only for the remainder of the original Warranty period. You acknowledge that any purchase of the Product from any party other than SHP or its authorised distributors or agents will be at your risk, and on the assumption that the Purchaser has complied with the terms of the Warranty.

### SUBMITTING A CLAIM UNDER THE WARRANTY

You should retain your Specific Product Warranty as well as the Product name and any serial numbers for your records in the event you need to file a claim. In the event of a manufacturing defect, you must notify SHP in writing of such defect, within 30 days after your discovery of the defect, by sending a claim notice to or phoning: SHP, 398 Naxos Way, Keysborough Victoria, 3173, Australia. Phone: (03) 8788 5900.

Your notice to SHP must be accompanied by:

- proof of purchase and delivery date to establish that you are the original owner of the Product, or have purchased the Product from the original owner of the Product;
- a sample of the Product for testing if requested by SHP; and
- photographs of the defective Product.

Your submission of the claim notice and the accompanying materials will be at your own expense. SHP may also require you to return the Product to it at your own expense. Notice to your contractor or dealer, or SHP's distributor or agent, is NOT notice to SHP.

Within a reasonable time after proper notification, SHP will evaluate your claim and resolve it in accordance with the terms of your Specific Product Warranty. Any replacement Product or repaired Product will, at SHP's election, be delivered to your nominated address by SHP, or made available for your collection at an address nominated by SHP.

### LIMITED WARRANTY

To the maximum extent permitted by applicable laws and regulations in each relevant jurisdiction, your Specific Product Warranty is exclusive and replaces all other warranties, whether express or implied, whether by statute, at law or in equity, including any and all implied warranties of merchantability and fitness for a particular purpose. Your Specific Product Warranty is your exclusive warranty from SHP and represents the sole remedy available from SHP to you, as owner of a Product. SHP makes no other representations, warranty, condition, or guarantee of any kind other than that stated therein. SHP will not be liable in any event for consequential, punitive, special, incidental, indirect or other similar damages of any kind, including injury to persons, damage to property, loss of income, profit or business, or any other indirect loss arising from or caused in any way by the defective Product, whether for breach of warranty, negligence, strict liability in tort, or for any other cause. You acknowledge that you accept the risk and judgement of SHP as to whether or not the Product is fit for any particular purpose, and you indemnify SHP from every liability, loss, damage, cost or expense directly or indirectly incurred or suffered by SHP caused by or contributed to by your failure to:

- adequately provide or display safety markings or safety information on or with the Products;
- comply with any law in respect of the Products or their use;
- take any reasonable precaution to bring to the attention of any potential users of the Products any dangers associated with Products; or
- any negligence or breach of duty on your part.

Your Warranty shall be governed by the laws of the State of Victoria, Australia, without regard to principles of conflicts of laws.

**IMPORTANT NOTE:** Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages so the above limitations or exclusions may not apply. This warranty gives you specific legal rights, and you may have other rights which vary from jurisdiction to jurisdiction. Nothing in this Warranty is intended to have the effect of contracting out of any applicable provisions of any legislation which applies to the purchase of the Product in a particular jurisdiction, except to the extent permitted under the law of that jurisdiction. If liability for breach by SHP of a warranty or condition or any other liability imposed on SHP by legislation which cannot be excluded may be limited, SHP's liability is limited to the extent permitted by law, and if liability may be limited in any one of a number of ways, SHP's liability is limited in any one of the permitted ways chosen by SHP in its absolute discretion.

### MODIFICATION OF WARRANTY

The Warranty may be modified or modified. No one, including any representative or employee of SHP, has authority to assume any additional liability or responsibility for SHP in connection with the Product except as described in this Warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.