

User Manual



WHAT'S IN THE BOX

- Momentum 2.0 Smart Watch
- Magnetic Charging Cable
- 1 x Spare Watch Band.
- User Manual

Note: A USB wall adapter (not included) is required to charge the watch.

SPECIFICATIONS

Screen Size:	1.4"
Screen Type:	Touchscreen
Screen Resolution:	240 x 240 pixels
Strap Sizes:	70mm and 118mm
IP Rating:	IP68
APP:	HitFit Pro
Bluetooth Version:	5.0
Pairing Name:	VF-M2
Battery:	Lithium ion 3.7V 180mAh
Charging:	Use no more than 5V/2A (10W)
Charging Time:	Up to 4 hours
Battery Runtime:	5 – 7 days depending on usage or 10 – 15 days standby
Product Dimensions:	36.9 x 40.9 x 10.5mm
Weight:	19g

FEATURES

- Track daily activities such as Sports, Heart rate and Sleep.
- IP68 Waterproof - 1.5 meter depth for max 30 minutes.
- Touchscreen.
- Various watch faces.
- Built-in games.
- Up to 7-day runtime.

CHARGING



- Connect the charging cable to the watch as pictured.
- Connect the other end of the cable to a USB Wall Adapter or USB Power source no higher than 5V/2A (10W).
- Please charge the battery to 100% before 1st use.


CONTROLS



- **Power On:** Press and hold the button for 5 seconds to turn watch on.

CONTROLS

continued...

- **Power Off:** On the settings function menu click the SETTING icon, then SYSTEM, then SHUT DOWN, then tap  to turn the watch off.

- **Menu Controls:** Swipe the screen to navigate and tap function icon to enter corresponding sub-menu.

- **Wake-Up Screen:** Tap the power button or raise wrist (setting must be enabled in the APP).

CONTROLS

continued...

- **Settings Function Menu:**


Swipe down from clock interface for Battery, Bluetooth, Date, Brightness, Sports, Alarms and Settings functions.

- **Other Function Menu:**


Swipe up from clock interface for Storage Info, Heart rate monitoring and Daily Activity.

MAIN FUNCTION MENUS


Swipe as indicated below for the function menus.



Change Watch Screen: Tap and hold the screen in clock view to enter watch screen menu.



REPLACING THE STRAP



- Move the quick release switch on the back of the watch band to unlock.
- Replace with another strap making sure it clicks in place.

SOFTWARE



- Scan the QR code to download the Hit FitPro APP or download directly from your smartphone's APP store by searching "Hit FitPro".

PAIRING THE WATCH TO HIT FITPRO APP

- Turn on the watch and it will automatically go into pairing mode (when not already paired with another device).
- Turn on Bluetooth on your smartphone then open the Hit FitPro APP.
- Select DEVICE then FIND WATCH option on the Hit FitPro APP.


PAIRING THE WATCH TO HIT FITPRO APP

continued...

- Once the device is found, tap the device name “VF-M2” to finish pairing.
- To unpair the watch use the APP or Bluetooth settings on your connected device

PAIRING THE WATCH TO HIT FITPRO APP

continued...



Note: For correct operation of all Hit FitPro APP functions please allow the APP access to all permissions on your smartphone when prompted. This includes access to GPS, Notifications and Bluetooth.

MAIN FUNCTIONS



DAILY ACTIVITY

Display total steps, walking distance and calories burnt. The data is cleared at midnight every day.



SPORTS

Choose between Walking, Running, Climbing, Riding and Free Sports modes.

MAIN FUNCTIONS

continued...



GAME

Choose between 2048, Candy Crush, Fly a Plane and Maze games.



ALARMS

Set alarms using the Hit FitPro APP which can be displayed using the Alarms function on the watch.



SPORTS RECORD

Check information on any sports activities recorded.


MAIN FUNCTIONS

continued...



SLEEP

Check previous night's sleep information. Sleep measurement time is between 9:30pm – 12pm the next day.



DATE & TIME

Set the date and choose time display mode.

MAIN FUNCTIONS

continued...




HEART RATE

Measure the heart rate.

Swipe left on main interface and select heart rate icon.

After the measurement is completed, the watch will vibrate.

During measurement the value will be zero and will only show the final value after measurement.



MAIN FUNCTIONS

continued...



MESSAGE

When connected to your smartphone and the setting is enabled on the APP the watch will receive notifications from your phone.



TIMER

Swipe left on main interface to select the Timer icon to start Stopwatch.



SETTING

When connected to your smartphone and the setting is enabled on the APP the watch will receive notifications from your phone.

MAIN FUNCTIONS

continued...



Change
Language



Change Screen Dial,
Brightness, Screen Time
and Wrist Sense Wake
settings.



Turn ON/OFF Do Not
Disturb mode.



Set Vibration intensity.



System Version,
Shut Down Watch and
Reset Watch settings.

TROUBLESHOOTING

Mobile phone cannot connect to the Watch.

1. Pair the watch via the HitFit Pro APP and not directly from the smartphone's Bluetooth settings menu.
2. Try updating the HitFit Pro APP to the latest version.
3. On your smartphone quit all APPs, reactivate the phone's Bluetooth, and re-connect using the APP only.

TROUBLESHOOTING

continued...

Watch has no message or call reminders.

1. Activate the “Message Push” option in the HitFit Pro APP.
2. Check your phone has allowed all permissions to the HitFit Pro APP.

TROUBLESHOOTING

continued...

Bluetooth disconnects frequently.

1. The maximum Bluetooth range is 10m but we recommend keeping the phone and watch within 7 meters of each other for maximum signal strength.
2. Any type of shielding between the watch and the phone will affect the connection. Other devices and metal jewellery may also interfere with the Bluetooth connection signal.
3. Test the Bluetooth function of the phone is operating normally with other devices.

DISCLAIMER

Wearing Smart Watch devices may cause skin irritation.

Prolonged contact with the watch or band may contribute to skin irritation or allergies in some users. To reduce irritation, follow these basic care instructions:

1. Keep the watch and band clean.
2. Keep the watch, band, and your skin area underneath dry.
3. Do not wear the watch too tight
4. Give your wrist a rest by removing the band for an hour after extended wear.

If you feel discomfort on your skin or have noticed a rash developing, please discontinue use and consult a doctor.

Laser and V-Fitness products are tools to provide you with information to encourage an active and healthy lifestyle. They rely on sensors that track your movement and other metrics. The data and information provided by these devices are an estimation of the metrics tracked but may not be precisely accurate. Our products are not medical devices, and the data provided by them is not intended to be used for medical purposes. They are not intended to diagnose, treat, cure, or prevent any disease. Laser recommends you consult your doctor before engaging in any exercise routines.

WARRANTY AGAINST DEFECTS

Laser warrants your new product to be free from defects in materials and workmanship for 12 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates.

Through a network of retailers and resellers, Laser will provide you with your choice of a refund, repair, or exchange (where possible) for this product if it becomes defective within the warranty period. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse, normal wear and tear, neglect, or improper storage. **Please retain your receipt as proof of purchase**

How to make a product warranty claim:

1. Find your receipt with date of purchase. If this is not available, Laser will make an assessment based on the date of manufacture, condition of the product and type of defect.
2. Please contact your original place of purchase. They will assess the nature of the fault and refund or replace the product as per their store refund or warranty policy.
3. If your original place of purchase cannot be contacted, please contact Laser with a description of the fault. To assist our team in providing you with a quick resolution, please include any photos and/or a short video demonstrating the fault with your product.
 - Phone: (02) 9870 3355
 - Email: support@laserco.com.au
 - Online: www.laserco.net/support/warranty and follow the website instructions
 - Business Address: U1 6-8 Byfield Street, Macquarie Park, 2113, NSW, Australia
4. Laser will review your claim and in the first instance, attempt to troubleshoot and resolve the issue for you without the need to return the product.
5. If it is determined via troubleshooting that your product may be faulty, our team will provide instructions to have the product returned for assessment. If the product does need to be returned within the warranty period, Laser will arrange return shipping at no cost to you.
6. Once we receive the product, our experienced technicians will assess it and determine how best to resolve the issue.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For more
helpful guides
visit us at



LASER
www.youtube.com/LasercoAu



SCAN ME